

GP-9M

Roland Digital Piano
Owner's Manual



Here's What You Can Do

Having Fun Playing the Piano

Playing Various Tones

page 13

In addition to grand piano tones for use in concerts, this instrument features a wide range of built-in instrument tones. Use these tones as you like according to the song you're playing and the mood.

Listening to and Practicing with the Built-in Songs

page 17

This piano comes with built-in songs that are well-known in a variety of genres from classical to jazz, as well as songs for practicing and more. You can just listen to and enjoy these songs as-is, or you can use the metronome and change the tempo to play along with the built-in songs.

Recording Your Performance

page 23

You can record your own keyboard performance, and then play it back to hear how you did. By listening back to what you played on the spot, you can improve what you did for the next time, or copy your performance to a USB flash drive as a song.

Enjoy Listening to Songs Played by the Auto Player

page 19

This instrument features an "Moving Key" function, which automatically plays a variety of song data on the keys of the piano, including the built-in songs and recorded songs, songs copied to a USB flash drive and so on.

Adjusting the Piano

Changing the playing feel (key touch)

page 15

You can adjust the how the keyboard feels (the key touch) when you play, according to your tastes.

Making the pitch match other instruments

page 26

When playing in an ensemble or similar situations, you can adjust the reference pitch of this piano to match its tuning with other instruments (master tuning).

Creating Your Own Piano Tone (Piano Designer)

page 26

Adjusts the different elements of the grand piano sound, letting you customize the piano sound as you like.

Registering your favorite settings (Registration)

page 15

You can register your customized settings and then instantly switch between settings for each song or for different players.

More Ways to Further Enjoy This Instrument

Using a Mic to Sing and Play Along

page 7

When you connect your mic to the piano, you can hear the mic's sound from the piano speakers along with the sound of the piano and the song that's playing back.

Playing music through the piano's speakers (Bluetooth® Audio)

page 28

You can connect your smartphone or tablet to this instrument and listen to your favorite songs through the piano's speakers. This lets you "play along" with the performances of the musicians you admire.

Connecting to an app to enjoy various added features (via Bluetooth MIDI)

page 29



By connecting this piano to an app, you can select even more varied tones, discover new music via Roland Cloud, and use features such as digital sheet music to assist you when you practice... all of which lets you experience a new world of piano performance.

Downloading the app

iOS/iPadOS

Android

Download the app for your smartphone or tablet for use with the piano.



This app lets you view sheet music in digital form, practice songs as if you were playing a game, or keep a record of your practicing.

Before using this unit, carefully read "IMPORTANT SAFETY INSTRUCTIONS" (inside front cover), "USING THE UNIT SAFELY" (p. 2), and "IMPORTANT NOTES" (p. 4). After reading, keep the document(s) where it will be available for immediate reference.

USING THE UNIT SAFELY

INSTRUCTIONS FOR THE PREVENTION OF FIRE, ELECTRIC SHOCK, OR INJURY TO PERSONS

About ⚠ WARNING and ⚠ CAUTION Notices

⚠ WARNING	Used for instructions intended to alert the user to the risk of death or severe injury should the unit be used improperly.
⚠ CAUTION	Used for instructions intended to alert the user to the risk of injury or material damage should the unit be used improperly. * Material damage refers to damage or other adverse effects caused with respect to the home and all its furnishings, as well to domestic animals or pets.

About the Symbols

	The ⚠ symbol alerts the user to important instructions or warnings. The specific meaning of the symbol is determined by the design contained within the triangle. In the case of the symbol at left, it is used for general cautions, warnings, or alerts to danger.
	The ⚡ symbol alerts the user to items that must never be carried out (are forbidden). The specific thing that must not be done is indicated by the design contained within the circle. In the case of the symbol at left, it means that the unit must never be disassembled.
	The ⚡ symbol alerts the user to things that must be carried out. The specific thing that must be done is indicated by the design contained within the circle. In the case of the symbol at left, it means that the power-cord plug must be unplugged from the outlet.

ALWAYS OBSERVE THE FOLLOWING

⚠ WARNING

Make sure that the power cord is grounded

Connect mains plug of this model to a mains socket outlet with a protective earthing connection.



To completely turn off power to the unit, pull out the plug from the outlet

Even with the power switch turned off, this unit is not completely separated from its main source of power. When the power needs to be completely turned off, turn off the power switch on the unit, then pull out the plug from the outlet. For this reason, the outlet into which you choose to connect the power cord's plug should be one that is within easy reach and readily accessible.



Concerning the Auto Off function

The power to this unit will be turned off automatically after a predetermined amount of time has passed since it was last used for playing music, or its buttons or controls were operated (Auto Off function). If you do not want the power to be turned off automatically, disengage the Auto Off function (p. 36).



Do not disassemble or modify by yourself

Do not carry out anything unless you are instructed to do so in the owner's manual. Otherwise, you risk causing malfunction.



Do not repair or replace parts by yourself

Be sure to contact your dealer, a Roland service center, or an official Roland dealer. For a list of Roland service centers and official Roland dealers, refer to the Roland website.



Do not use or store in the following types of locations

- Subject to temperature extremes (e.g., direct sunlight in an enclosed vehicle, near a heating duct, on top of heat-generating equipment); or are
- Damp (e.g., baths, washrooms, on wet floors); or are
- Exposed to steam or smoke; or are
- Subject to salt exposure; or are
- Exposed to rain; or are
- Dusty or sandy; or are
- Subject to high levels of vibration and shakiness; or are
- Placed in a poorly ventilated location.



Lock the casters

When installing the piano, be sure to fasten the casters using the supplied caster cups.



⚠ WARNING

Do not place in an unstable location

Otherwise, you risk injury as the result of the unit toppling over or dropping down.



Connect the power cord to an outlet of the correct voltage

The unit should be connected to a power supply only of the type described as marked on the bottom of unit.



Use only the supplied power cord

Use only the attached power cord. Also, the supplied power cord must not be used with any other device.



Do not bend the power cord or place heavy objects on it

Otherwise, fire or electric shock may result.



Avoid extended use at high volume

Use of the unit at high volume for extended periods of time may cause hearing loss. If you ever experience any hearing loss or ringing in the ears, you should immediately stop using the unit and consult a specialized physician.



Do not allow foreign objects or liquids to enter unit; never place containers with liquid on unit

Do not place containers containing liquid (e.g., flower vases) on this product. Never allow foreign objects (e.g., flammable objects, coins, wires) or liquids (e.g., water or juice) to enter this product. Doing so may cause short circuits, faulty operation, or other malfunctions.



Turn off the unit if an abnormality or malfunction occurs

In the following cases, immediately turn off the power, remove the power cord from the outlet, and contact your dealer, a Roland service center, or an official Roland dealer for service.



- The power cord has been damaged; or
- If smoke or unusual odor occurs; or
- Objects have fallen into, or liquid has been spilled onto the unit; or
- The unit has been exposed to rain (or otherwise has become wet); or
- The unit does not appear to operate normally or exhibits a marked change in performance.

For a list of Roland service centers and official Roland dealers, refer to the Roland website.

⚠ WARNING

Be cautious to protect children from injury

Always make sure that an adult is on hand to provide supervision and guidance when using the unit in places where children are present, or when a child will be using the unit.



Do not drop or subject to strong impact

Otherwise, you risk causing damage or malfunction.



Do not share an outlet with an unreasonable number of other devices

Otherwise, you risk overheating or fire.



Do not use overseas

Before using the unit in overseas, consult with your retailer, the nearest Roland service center, or an authorized Roland distributor. For a list of Roland service centers and official Roland dealers, refer to the Roland website.



Use due care when handling the lid

- The lid should be opened and closed only by an adult.
- The lid must not be opened too far (we recommend that you do not open it by more than about 30 degrees). If opened to an extreme degree, you risk damaging the piano or having the lid fall unexpectedly. Also, when opening the lid, make sure that no one is in the way.



Don't place burning objects on the unit

Don't place any burning object (such as a candle) on the unit.



Be aware of weather conditions

Use the apparatus in moderate climates.



CAUTION

When disconnecting the power cord, grasp it by the plug

To prevent conductor damage, always grasp the power cord by its plug when disconnecting it.



Periodically clean the power plug

An accumulation of dust or foreign objects between the power plug and the power outlet can lead to fire or electric shock.

At regular intervals, be sure to pull out the power plug, and using a dry cloth, wipe away any dust or foreign objects that may have accumulated.



Disconnect the power plug whenever the unit will not be used for an extended period of time

Fire may result in the unlikely event that a breakdown occurs.



Route all power cords and cables in such a way as to prevent them from getting entangled

Injury could result if someone were to trip on a cable and cause the unit to fall or topple.



Lock all casters if mobility presents danger

In every situation where the unexpected movement of this unit could present a danger (such as when it's set up on a stage, or when it's being transported inside a vehicle), make sure to lock all the casters.



Avoid climbing on top of the unit, or placing heavy objects on it

Otherwise, you risk injury as the result of the unit toppling over or dropping down.



Never connect/disconnect a power plug if your hands are wet

Otherwise, you could receive an electric shock.



Cautions when moving this unit

If you need to move the instrument, take note of the precautions listed below. At least two persons are required to safely lift and move the unit. It should be handled carefully, all the while keeping it level. Make sure to have a firm grip, to protect yourself from injury and the instrument from damage.



- Close the lid.
- Fold down the music rest.
- Close the keyboard cover.
- Close the flap (p. 10)
- Check to make sure the screws securing the unit to the stand have not become loose. Fasten them again securely whenever you notice any loosening.
- Disconnect the power cord.
- Disconnect all cords coming from external devices.

Before cleaning the unit, disconnect the power plug from the outlet

If the power plug is not removed from the outlet, you risk receiving an electric shock.



Whenever there is a threat of lightning, disconnect the power plug from the outlet

If the power plug is not removed from the outlet, you risk causing malfunction or receiving an electric shock.



CAUTION

Take care so as not to get fingers pinched

When handling the following moving parts, take care so as not to get fingers, etc., pinched. An adult should always be in charge of handling these items.



- Top lid (p. 10)
- Music rest (p. 10)
- Keyboard cover (p. 11)
- Top stick (p. 11)
- Pedals (p. 12)
- Flap (p. 10)

Keep small items out of the reach of children

To prevent accidental ingestion of the parts listed below, always keep them out of the reach of small children.



- Included Parts
- Screws

Use due care when handling the top lid and keyboard cover

- To prevent the lid from dropping, always make sure to lock the top stick in its receptacle. Also, make sure to keep supporting the top lid with your hands until the top stick is securely locked.
- When opening and closing the keyboard cover, use due caution so as not to get your fingers pinched. Whenever a child uses the unit, an adult should be on hand to provide guidance and supervision.
- Do not close the cover if there are any objects, such as sheet music, remaining on top of the keyboard.
- As a safety precaution, always make sure to lower the top lid and close the keyboard cover before moving the piano.



IMPORTANT NOTES

Power Supply

- Do not connect this unit to same electrical outlet that is being used by an electrical appliance that is controlled by an inverter or a motor (such as a refrigerator, washing machine, microwave oven, or air conditioner). Depending on the way in which the electrical appliance is used, power supply noise may cause this unit to malfunction or may produce audible noise. If it is not practical to use a separate electrical outlet, connect a power supply noise filter between this unit and the electrical outlet.

Placement

- Using the unit near power amplifiers (or other equipment containing large power transformers) may induce hum. To alleviate the problem, change the orientation of this unit; or move it farther away from the source of interference.
- This unit may interfere with radio and television reception. Do not use this unit in the vicinity of such receivers.
- Noise may be produced if wireless communications devices, such as cell phones, are operated in the vicinity of this unit. Such noise could occur when receiving or initiating a call, or while conversing. Should you experience such problems, you should relocate such wireless devices so they are at a greater distance from this unit, or switch them off.
- Do not allow lighting devices that normally are used while their light source is very close to the unit (such as a piano light), or powerful spotlights to shine upon the same area of the unit for extended periods of time. Excessive heat can deform or discolor the unit.
- When moved from one location to another where the temperature and/or humidity is very different, water droplets (condensation) may form inside the unit. Damage or malfunction may result if you attempt to use the unit in this condition. Therefore, before using the unit, you must allow it to stand for several hours, until the condensation has completely evaporated.
- Do not allow objects to remain on top of the keyboard. This can be the cause of malfunction, such as keys ceasing to produce sound.
- Do not paste stickers, decals, or the like to this instrument. Peeling such matter off the instrument may damage the exterior finish.
- Do not place containers or anything else containing liquid on top of this unit. Also, whenever any liquid has been spilled on the surface of this unit, be sure to promptly wipe it away using a soft, dry cloth.

Maintenance

- Never use benzene, thinners, alcohol or solvents of any kind, to avoid the possibility of discoloration and/or deformation.

Care of the Keyboard

- Do not write on the keyboard with any pen or other implement, and do not stamp or place any marking on the instrument. Ink will seep into the surface lines and become unremovable.
- Do not affix stickers on the keyboard. You may be unable to remove stickers that use strong adhesives, and the adhesive may cause discoloration.
- To remove stubborn dirt, use a commercially available keyboard cleaner that does not contain abrasives. Start by wiping lightly. If the dirt does not come off, wipe using gradually increasing amounts of pressure while taking care not to scratch the keys.

Moving Key

- Do not prevent the keys from moving normally, such as by forcibly pressing on keys while the Moving Key function is in use or by forcibly lifting up keys that are pressed down. Doing so may cause a malfunction.

Concerning the Care of the Unit (Mirror Finish)

- The surface of this unit has been polished so as to create a high-gloss, mirror-like finish. Since this beautiful finish is as delicate as that of the highest quality, wood-crafted furniture, it needs to be cared for at regular intervals. Please make sure to observe the following when caring for the unit.
 - For routine care, gently clean the surface using a soft cloth or a piano-use feather duster. You must avoid applying any force, since even the tiniest particles of sand or grit can produce scratches if you wipe too hard.
 - If the finish loses its luster, use a soft cloth dampened with some polishing liquid to evenly wipe the surface of the unit.
 - Avoid using detergents or other cleaners, as they can cause the surface finish to deteriorate. This may lead to the formation of cracks or other imperfections. Also, do not use chemically-enhanced cleaning cloths.
- Precautions concerning the use of polishing agents
 - Refer to the instructions that came with the polishing agent for instructions on its proper use.
 - Use only polishing agents that are designed specifically for use on the mirror finishes of pianos. By using any other product, you risk causing scratches, deformation, discoloration, etc. To purchase an appropriate product, please consult the nearest musical instrument store.
 - Use the product only on the portions of this unit that have a mirror-like finish, and using an even touch, apply it equally over the entire surface. If you apply more force in one place over another, you risk losing some of the luster of the finish.
 - Store in a location that is out of the reach of small children. If accidentally ingested, induce vomiting immediately. Then, see a doctor to obtain a diagnosis.

Repairs and Data

- Before sending the unit away for repairs, be sure to write down the needed information. Although we will do our utmost to preserve the data stored in your unit when we carry out repairs, in some cases, such as when the memory section is physically damaged, restoration of the stored content may be impossible. Roland assumes no liability concerning the restoration of any stored content that has been lost.

Additional Precautions

- Any data stored within the unit can be lost as the result of equipment failure, incorrect operation, etc. To protect yourself against the irretrievable loss of data, be sure to write down the needed information.
- Roland assumes no liability concerning the restoration of any stored content that has been lost.
- Use a reasonable amount of care when using the unit's buttons, sliders, or other controls; and when using its jacks and connectors. Rough handling can lead to malfunctions.
- Never strike or apply strong pressure to the display.
- When disconnecting all cables, grasp the connector itself—never pull on the cable. This way you will avoid causing shorts, or damage to the cable's internal elements.
- A small amount of heat will radiate from the unit during normal operation.
- To avoid disturbing others nearby, try to keep the unit's volume at reasonable levels.
- The sound of keys being struck and vibrations produced by playing an instrument can be transmitted through a floor or wall to an unexpected extent. Please take care not to cause annoyance to others nearby.
- Do not apply undue force to the music rest while it is in use.
- Do not use connection cables that contain a built-in resistor.

Using External Memories

- Please observe the following precautions when handling external memory devices. Also, make sure to carefully observe all the precautions that were supplied with the external memory device.
 - Do not remove the device while reading/writing is in progress.
 - To prevent damage from static electricity, discharge all static electricity from your person before handling the device.

Caution Regarding Radio Frequency Emissions

- The following actions may subject you to penalty of law.
 - Disassembling or modifying this device.
 - Removing the certification label affixed to the back of this device.
 - Using this device in a country other than where it was purchased

Intellectual Property Right

- It is forbidden by law to make an audio recording, video recording, copy or revision of a third party's copyrighted work (musical work, video work, broadcast, live performance, or other work), whether in whole or in part, and distribute, sell, lease, perform or broadcast it without the permission of the copyright owner.
- Do not use this product for purposes that could infringe on a copyright held by a third party. We assume no responsibility whatsoever with regard to any infringements of third-party copyrights arising through your use of this product.
- The copyright of content in this product (the sound waveform data, style data, accompaniment patterns, phrase data, audio loops and image data) is reserved by Roland Corporation.
- Purchasers of this product are permitted to utilize said content (except song data such as Demo Songs) for the creating, performing, recording and distributing original musical works.
- Purchasers of this product are NOT permitted to extract said content in original or modified form, for the purpose of distributing recorded medium of said content or making them available on a computer network.
- Roland is either registered trademarks or trademarks of Roland Corporation in the United States and/or other countries.
- Company names and product names appearing in this document are registered trademarks or trademarks of their respective owners.
- This product contains eParts integrated software platform of eSOL Co.,Ltd. eParts is a trademark of eSOL Co., Ltd. in Japan.
- The **Bluetooth**® word mark and logos are registered trademarks owned by **Bluetooth SIG, Inc.** and any use of such marks by Roland is under license.
- This Product uses the Source Code of µT-Kernel under T-License 2.0 granted by the T-Engine Forum (www.tron.org).
- The "Chinese language font MORISAWA SONG GB2313BMP12" used by this product is provided by Morisawa Corporation, and copyright to the font data is the property of that corporation.
- This product includes third party open source software. Copyright © 2009-2018 Arm Limited. All rights reserved. Copyright © 2018 STMicroelectronics. All rights reserved. Licensed under the Apache License, Version 2.0 (the "License"); You may obtain a copy of the License at <http://www.apache.org/licenses/LICENSE-2.0>
Copyright © 2018 STMicroelectronics. All rights reserved. This software component is licensed by ST under BSD 3-Clause license, the "License"; You may obtain a copy of the License at <https://opensource.org/licenses/BSD-3-Clause>
- This product is using the Jansson (<http://www.digip.org/jansson/>) source code. Copyright © 2009-2016 Petri Lehtinen <petri@digip.org> Released under the MIT license <http://opensource.org/licenses/mit-license.php>

Contents

USING THE UNIT SAFELY	2	Recording Your Performance	23
IMPORTANT NOTES	4	Recording Your Keyboard Performance	23
Main Specifications	5	Deleting a Saved Song	23
Panel Descriptions	6	Advanced Recording Methods	24
Settings Saved Even If the Power Is Turned Off	9	Creating Your Own Piano Tone (Piano Designer)	26
Disabling the Buttons (Panel Lock)	9	Adjusting the Sound of the Overall Piano	26
Before You Play	10	Editing the Grand Piano Tone	27
Using the Music Rest	10	Connecting the Piano and a Mobile Device via Bluetooth® ..	28
Opening/Closing the Top Lid	10	Here's What You Can Do	28
Opening/Closing the Keyboard Cover (Turning the Power On/Off) ..	11	Play Music Through the Piano's Speakers	28
Turning the Operating Panel Lights On/Off	11	Using the Piano with an App	29
Adjusting the Overall Volume	12	Convenient Functions	31
Using the Headphones	12	Loading/Saving Your Favorite Settings and Piano Setups	31
Using the Pedals	12	Initializing the Memory (Format Media)	32
Basic Operations of Functions	12	Restoring the Factory Settings (Factory Reset)	32
Performing	13	Configuring the Various Settings	33
Playing Various Tones	13	Function Mode	33
Practicing with the Metronome	16	Keyboard Mode	37
Listening to Songs	17	Troubleshooting	38
Playing Back a Song	17	Error Messages	40
Having Fun with the Moving Key Function	19	Tone List	41
Making the Keys Play Along with the Internal Songs or Songs		Internal Song List	43
You've Recorded, or with Song Data Copied to a USB Flash Drive ..	19		
Using the Roland Piano App to Play the Keyboard Along with a			
Song	19		
Making the Keyboard Play Along with Commercially Available			
Data	21		

Main Specifications

Sound generator	Piano Reality Modeling Concert Sound Engine (with Piano Reality Ambience)
Keyboard	Piano Reality Hybrid Concert Keyboard (88keys): with Escapement, Ebony/Ivory Feel, Dynamic Sensor Acceleration Technology and Haptic Key Vibration
Moving key	Standard MIDI Files (Format 0, 1, Moving key parts assignable) Player piano data (with Moving key format)
Bluetooth	Bluetooth Ver 4.2 Supported profiles: A2DP (Audio), GATT (MIDI over Bluetooth Low Energy) Supported codec: SBC (compatible with SCMS-T content protection)
Power consumption	120 W Approximate power consumption when playing the piano at medium volume: 30 W Approximate power consumption when the moving key is operated: 56 W Power consumption when sound has not been played after power-on: 28 W
Dimensions	Top opened (with music rest) 1,445 (W) x 1,501 (D) x 1,787 (H) mm 56-15/16 (W) x 59-1/8 (D) x 70-3/8 (H) inches Top closed (with music rest): 1,440 (W) x 1,501 (D) x 999 (H) mm 56-3/4 (W) x 59-1/8 (D) x 39-3/8 (H) inches
Weight	188.0 kg/414 lbs 8 oz
Accessories	Owner's Manual, "Roland Piano Masterpieces", Leaflet "Leaflet Stand Assembly", Power cord, Maintenance set, Key cover, Caster cups, Headphone hook, Cord clamps

* This document explains the specifications of the product at the time that the document was issued. For the latest information, refer to the Roland website.

English

日本語

Deutsch

Français

Italiano


Español

Português




Nederlands

简体中文

Panel Descriptions



* To prevent malfunction and equipment failure, always turn down the volume, and turn off all the units before making any connections.



1 [⏻] (Power) button

Turns the power on/off.
You can open and close the keyboard cover to turn the piano on/off (p. 11).

2 [🔊] (Volume) knob

Adjusts the volume of the entire piano.
This adjusts the volume for playing the piano or playing back the songs.
If headphones are connected, it adjusts the volume of the headphones (p. 12).

3 [⚙️] (Function) button

Lets you access function mode, where you can change various settings (p. 33).

4 [🏠] (Ambience) button

Adds reverberation that makes it sound like you're playing in a spacious place like a concert hall or a cathedral. Change the type of reverberation to simulate the sound of playing the piano in different places (p. 13).

5 [🎹] (Keyboard Mode) button

Use this to access Keyboard mode, where you can change various keyboard settings (p. 37).

6 [🎛️] (Piano Designer) button

Adjusts various elements of the piano's sound, allowing you to customize the sound to your preference (p. 26).

7 Tone [🏠] (Grand) [🎹] (Upright / Classical) [🎹] (E.Piano / Organ) [🎹] (Other) buttons

Select the sound that's played by the keyboard (p. 13).
Press the [📄] (Registration) button to switch these to the [1] [2] [3] [4] buttons.

8 [📄] (Registration) button

Use this button to select and register the Registration settings (p. 15).

9 Display

This shows information such as the tone name, song name, tempo, and time signature.

10 [-] [+] (selection) button

Changes the item or value shown onscreen (p. 12).

11 [⏪] (Exit) button

Returns to the previous screen, or exits the current screen (p. 12).

12 [↵] (Enter) button

Confirms an item or value shown in the screen (p. 12).


13 [🎵] (Metronome) button

Turns the metronome on/off (p. 16).

14 [🎵] (Tempo) button

Changes the tempo of the metronome or song.

- Changing the metronome tempo (p. 16)
- Changing the song tempo (p. 17)



15 [Song] (Song) button

Selects the built-in song or recorded performance that will be played back (p. 17).

16 [Cue up] (Cue up) button

Selects the beginning of the song (p. 17, p. 23).

17 [Play/Stop] (Play/Stop) button

Plays/stops the song playback, or start/stops recording (p. 17, p. 23).

18 [Measure] (Measure) button

Moves the playback position forward or backward to a desired measure in the song (p. 17, p. 23).

19 [Recording] (Recording) button

Records the performance that you play (p. 23).

20 [part] (part) button

Lets you select the performance part (right-hand, left-hand, accompaniment) that will play back. This also lets you record parts separately (p. 17, p. 24).

21 Top lid

The top lid can be opened. Opening the top lid allows the sound to be more clearly defined; closing it produces a softer sound (p. 10).

22 Music Rest

Place printed music here (p. 10).

23 Pedal

By pressing the pedals, you can apply effects to the sound of the piano.

You can also assign a variety of functions to the pedals.

- Apply effects to the sound of the piano (p. 12)
- Assign functions to the pedals (p. 34, p. 35)

24 USB Computer port

Here you can connect your computer via a USB cable (sold separately). If your computer is connected, performance data can be transferred between the piano and sequencer software (sold separately) on your computer, allowing you to produce or edit music.

25 USB Memory port

Here you can connect a USB flash drive. You can use it to record your piano performance as audio, or use the piano to play back music data (WAVE files, MIDI files, MP3 files) from the USB flash drive (p. 18, p. 25).

26 Input jack

Here you can connect a stereo mini-plug cable (commercially available) for connecting your audio player. The sound that's played back from your audio player can be heard from the piano's speakers. You can also play the piano along with the playback audio.

27 Output jacks (L/Mono, R)

Here you can connect external speakers via cables that are equipped with mono 1/4" plugs (commercially available). This is useful when you want to connect to external audio equipment and play in front of many people.


28 Phones jacks

Here you can connect stereo headphones. This piano has two headphone jacks, so two people can use headphones at the same time (p. 12).

29 Assignable Out connectors (R, L)

Use XLR cables (commercially available) to connect to different external speakers or audio equipment from the ones that are connected to the Output jacks. You can select the sound to be output (p. 36).

* Pin assignment of Assignable Out connectors



30 Mic jack

Connect a dynamic mic here. You can add reverberation to the input sound from the mic, to simulate a spacious place like a concert hall or a cathedral (p. 13).

31 Gain knob

Adjusts the volume of the mic input.

32 AC In jack

Connect the included power cord here.

English

日本語

Deutsch

Français

Italiano

Español

Português


Nederlands

简体中文

Panel Descriptions

Connecting the pedal cord and the power cord


1. Connect the pedal cord to the Pedal jack, and fasten the pedal cord with the single cable fastener.



NOTE


The pedal cord plug may be damaged if you rotate it while the plug is only halfway inserted.

Check the illustration above to make sure that the plug faces correctly before you insert it.



Do not rotate while plug is inserted!

2. Plug the power cord into an AC outlet.



Settings Saved Even If the Power Is Turned Off

This piano remembers the “settings that are saved automatically” even when the power is turned off and then on again. You can also configure your favorite settings (Registration), so that the instrument remembers the favorite settings you’ve saved. Other settings return to their default values when you turn the power off and on again.

Settings that are saved automatically

This piano automatically saves the following settings. These settings are remembered even if the power is turned off.

Setting	Page
Speaker Volume	p. 12
Headphones Volume	p. 12
Bluetooth On/Off	p. 33
Bluetooth Volume	p. 33
Bluetooth ID	p. 33
Song Volume SMF	p. 33
Song Volume Audio	p. 33
Input Volume	p. 33
USB Audio Input Vol.	p. 33
Player Piano Setting: Player Piano Mode	p. 34
Player Piano Setting: Audio Level	p. 34
Player Piano Setting: Audio Sync	p. 34
SMF Play Mode	p. 34
Count-in Measure	p. 34
Reg. Pedal Shift	p. 35
Language	p. 35
Display Contrast	p. 35
Screen Saver	p. 35
Touch Click Volume	p. 35
Volume Limit	p. 35
Haptic Key Vibration	p. 35
Power Off by the Lid	p. 36
Speaker Auto Mute	p. 36
Auto Off	p. 36
Master Tuning	p. 26
Temperament	p. 26
Temperament Key	p. 26
Metronome Type	p. 16
Beat	p. 16
Metronome Downbeat	p. 16
Metronome Pattern	p. 16
Metronome Volume	p. 16
Metronome Tone	p. 16
Rhythm Pattern	p. 16
Moving Key On/Off	p. 35
Moving Key Ch.	p. 36
Assignable Out	p. 36

Settings saved in Registration

Turn the “Registering Your Favorite Settings” (p. 15) setting on to save the following settings.

Setting	Page
Ambience Type	p. 13
Kbd Ambience	p. 13
Brilliance	p. 13
Keyboard Mode	p. 37
Kbd Transpose	p. 15
Key Touch	p. 15
Hammer Response	p. 15
Whole - Tone/Split - Right Tone/Dual - Tone 1	p. 14, p. 14
Split - Left Tone	p. 14
Split - Point	p. 14
Split - Balance	p. 14
Split - Left Shift	p. 14
Split - Right Shift	p. 14
Dual - Tone 2	p. 14
Dual - Balance	p. 14
Dual - Tone1 Shift	p. 14
Dual - Tone2 Shift	p. 14
Twin Piano Mode	p. 37
Song Transpose	p. 33
Damper Pedal Part	p. 34
Center Pedal	p. 34
Left Pedal	p. 35
MIDI Transmit Ch.	p. 35
Rotary speed	p. 13
Mic Ambience	p. 13

* This memorizes whether the keyboard transposition has been set or not.

Disabling the Buttons (Panel Lock)

To prevent settings from being accidentally changed while you perform, you can disable all buttons other than the [⏏] button and the [⦿] knob.


Lock the panel	Hold down the [⦿] button until the screen shows the “🔒” symbol.
Unlock the panel	Hold down the [⦿] button until the “🔒” symbol disappears.

Before You Play

Using the Music Rest

Setting up the music rest


1. Fold the flap of the top lid back to open it.



2. Gently raise the music rest.

* When raising the music rest, take care not to pinch your fingers between the moving part and the body of the unit. In places where small children are present, make sure that an adult provides supervision and guidance.


3. Fit the latch into one of the slots so that the music rest is at the desired angle.



Using the page retainers

You can make the page retainers stand up, so that the pages of your sheet music stay flat.

If not using them, leave them folded down.




Opening/Closing the Top Lid

Opening the top lid

- * The top lid must only be opened and closed by an adult.
- * When opening or closing the top lid, take care not to pinch your fingers between the moving part and the body of the unit. Pay special attention to this when using the unit where children are present.

1. Fold the flap of the top lid back to open it.
2. Firmly grasp the right side of the top lid (position A on the treble side, as shown in the illustration) with both hands, and gently pull the top lid up.




NOTE

- Don't pull up on the flap—make sure to pull up on the top lid side.
- Do not open or close the top lid while the flap is closed.
- Be careful not to open the top lid up too much (the lid should be opened to around a 30° angle). If the top lid is opened up too much, this might damage the piano unit or cause the top lid to fall down. Also, make sure that nobody is in the way before opening the top lid.
- Do not move the piano with the top lid still open. Doing so might make the top stick come out of the holder, causing the top lid to slam shut.

3. Prop up the top stick and insert it into the holder while supporting the piano lid with your other hand.

* When raising the lid stick, please be careful not to get your fingers pinched between the movable part and the panel. In places where small children are present, make sure that an adult provides supervision and guidance.

4. Move the tip of the top stick to lock it into place.




NOTE

- To prevent the top lid from falling down, make sure to lock the top stick in place into the holder. Don't take your hand off the top lid until the top stick is fully locked into the holder.
- Close the top lid when you are not using the piano.
- Follow these steps in reverse when closing the top lid.


About the top sticks and holders

This piano features two top sticks with different lengths. Use the different sticks to change how much the top lid opens.



Use the correct holder for the stick length, as shown below.

- Long top stick: use the inner holder (position B)
- Short top stick: use the outer holder (position C)




Opening/Closing the Keyboard Cover (Turning the Power On/Off)

Opening the keyboard cover (turning the power on)

1. Turn the volume of the devices connected to this instrument all the way down.
2. Open the keyboard cover.

The power turns on automatically.

When opening the keyboard cover, use both hands to lift it.



- * You might hear some sound when switching the unit on/off. However, this is normal and does not indicate a malfunction.
- * After turning on the power, do not touch any of the touch switches on the operating panel until the instrument starts up. The touch switches might become unresponsive as a result.
- * Do not use this instrument if there is condensation on the operating panel. This could cause the touch switches to malfunction.
- * Press the [⏻] button when the keyboard cover is opened.
- * If you have any objects (papers, metal objects, etc.) placed on top of the keyboard cover, do not open the cover. Otherwise, such objects may slip inside the instrument, and then become irrecoverable.

Closing the keyboard cover (turning off the power)

1. Turn the volume of the devices connected to this instrument all the way down.
2. Close the keyboard cover.

The power turns off automatically.

When closing the keyboard cover, use both hands to close it.

- * When opening the top, take care not to pinch your fingers between the moving part and the body of the unit. In places where small children are present, make sure that an adult provides supervision and guidance.
- * If you need to turn off the power completely, first turn off the unit, then unplug the power cord from the power outlet. Refer to "To completely turn off power to the unit, pull out the plug from the outlet" (p. 2).

MEMO


- You can also long-press the [⏻] button to turn off the power.
- When you disable the "Auto-Power Off When Keyboard Cover is Closed" (p. 36) setting in Function mode (p. 33), the power does not turn off when you close the keyboard cover.

Turning the Operating Panel Lights On/Off

When you want to focus on your playing, you can turn both the operating panel and the display off.

Turning off the operating panel

1. Press the [⏻] button.
A confirmation message appears.



2. Press the [⏻] button once again.
The operating panel and display turn off.

English

日本語

Deutsch

Français

Italiano

Español

Português

Nederlands

简体中文

Before You Play

MEMO

Only the [v] (Volume) knob and the [⏻] button can be used when the operating panel is off.

- * You can also long-press the [⏻] button to turn off the power.

Turning on the operating panel

1. While the operating panel and display are off, press the [⏻] button

The operating panel and display turn on.

Adjusting the Overall Volume

Turn the [v] knob to adjust the volume. The speaker volume and headphone volume can be set separately. If headphones are connected, this automatically switches to adjusting the volume of the headphones.



Turn the [v] knob

Turning the knob toward the right increases the volume, and turning the knob to the left decreases the volume.

Using the Headphones

Use headphones if you want to perform without the sound being heard nearby. This piano has two headphone jacks, so two people can use headphones at the same time.

MEMO

When you want to play a duet with someone else while listening to headphones, switch the piano to Twin Piano mode. This lets you play the piano as if it was two separate pianos.


1. Connect your headphones to the headphone jack.

When you connect headphones, sound is no longer heard from the piano's speakers.

2. Use the [v] knob to adjust the volume of the headphones.

MEMO

Whenever you are not using the headphones, you can hang them on the headphone hook.




Concerning the Auto Off function

The power to this unit will be turned off automatically after a predetermined amount of time has passed since it was last used for playing music, or its buttons or controls were operated (Auto Off function). If you do not want the power to be turned off automatically, disengage the Auto Off function (p. 36).

- * When the power is turned off, any settings you were editing will be lost. You must save settings that you want to keep (p. 9).
- * To restore power, turn the power on again.

Using the Pedals

By pressing the pedals, you can apply effects to the sound of the piano.



Damper pedal (right)	Use this pedal to sustain the sound. While this pedal is held down, notes will be sustained for an extended time even if you release your fingers from the keyboard. The resonance of the sound is affected by how deeply you press the pedal.
Sostenuto pedal (center)	The notes you are pressing when this pedal is depressed will be sustained.
Soft pedal (left)	This pedal is used to make the sound softer. Playing with the soft pedal depressed produces a sound that is not as strong as when otherwise played with the equivalent strength. The softness of the tone can be varied subtly by the depth to which you press the pedal.

- * When operating the pedal, take care not to pinch your fingers between the moving part and the piano unit. In places where small children are present, make sure that an adult provides supervision and guidance.
- * This piano is designed with a grand piano pedal arrangement. Note that this differs from the pedal operations and effects you can achieve on an upright piano.

Basic Operations of Functions

Use the [-] [+] (selection) buttons, the [⏻] (Enter) button and the [↶] (Back) button.



Change an on-screen item or value	Press the [-] [+] buttons
Confirm	Press the [⏻] button
Return to the previous screen / Exit the current screen	Press the [↶] button
Return to the default value	Long-press the [⏻] button

Playing Various Tones

Selecting the Type and Depth of Reverberation

This feature adds reverberation to the sound, as if you're playing in a spacious place like a concert hall or a cathedral. Change the "Ambience Type" to recreate the sound of playing the piano in different places.

1. Press the [F7] button.

The Ambience screen appears.



2. Press the [-] [+] buttons to select what to set, either the "Ambience Type", "Kbd Ambience" or "Brilliance".

3. Press the [E] button.

4. Press the [-] [+] buttons to select the type and value.

Ambience Type	Selects from various types of reverberation that are applied to the sound when you play the piano. Studio, Lounge, Concert Hall, Wooden Hall, Stone Hall, Cathedral
Kbd Ambience	Adjusts the depth of reverberation. Higher values produce deeper ambience; lower values produce shallower ambience. * The reverberation effect is not applied to audio files. 0-10
Brilliance	Higher values produce brighter sounds. -10-0-+10
Mic Ambience	Adjusts the depth of reverberation that's applied to the mic input sound. 0-10

5. To exit the settings, press the [F7] button.

The [F7] button goes dark.

Selecting a Tone

In addition to piano sounds, the piano lets you enjoy performing with many other sounds. There are four groups of tones; each tone button selects a group.

→ "Tone List" (p. 41)

Tone groups

Tone buttons	Explanation
Grand 	Lets you select one of the grand piano tones.
Upright / Classical 	Tones including cembalo (harpsichord), fortepiano and upright piano
E.Piano / Organ 	Tones including electric piano and organ * If you've selected an organ sound that provides a rotary effect which simulates the sound of rotating speakers, pressing the [E] button will switch the speed of the rotary effect
Other 	Various tones such as stringed instruments and drums

1. Press a tone button.

The tone group is selected. The name of the currently selected tone is shown.



2. Press the [-] [+] buttons.

You can select other tones in the tone group.



MEMO

The tone you previously selected is memorized for each tone button while the power is on. Select a tone for each tone button beforehand to instantly switch between tones.

Playing Different Tones with the Left and Right Hand

You can perform using different tones in the left and right regions of the keyboard, divided at a specific note. This setting is called "Split Play", and the point at which the keyboard is divided is called the "split point".

1. Press the [F6] button.
2. Press the [-] [+] buttons, select "Keyboard Mode" and then press the [F6] button.
3. Press the [-] [+] buttons to select "Split".
4. Press the [F6] button to exit Keyboard mode.

The split screen appears.



When you turn on the power, "Concert Piano" is selected as the right-hand tone and "A.Bass+Cymb" is selected as the left-hand tone.

When split turns on, the keyboard settings are as follows.

Split point (Power-up default): F#3



5. To exit split play, press the [F6] button to enter Keyboard Mode, and set "Keyboard Mode" to "Whole".

Changing the settings for Split Play

To edit the following settings, access the Split screen.

	Operation
Changing the left-hand tone (Split-Left Tone)	<ol style="list-style-type: none"> 1. Press the [F6] button so that "-" "+" is shown in the lowest line of the screen. 2. Press a tone button. The tone group is selected. 3. Press the [-] [+] buttons to select a tone.
Changing the right-hand tone (Split-Right Tone)	<ol style="list-style-type: none"> 1. Press the [F6] button so that "-" "+" is shown in the top line of the screen. 2. Press a tone button. The tone group is selected. 3. Press the [-] [+] buttons to select a tone.
Changing the point at which tones are separated (Split-Point)	<ol style="list-style-type: none"> 1. Press the [F6] button. This switches to Keyboard mode. 2. Press the [F6] button twice. The Split mode settings screen appears. 3. Press the [-] [+] buttons to access the screen of the item you want to set. 4. Press the [F6] button so that "-" "+" is shown in the bottom line of the screen. 5. Press the [-] [+] buttons to select the value that you want to change.
Changing the volume balance of the left-hand tone and right-hand tone (Split-Balance)	<ol style="list-style-type: none"> 1. Press the [F6] button. This switches to Keyboard mode. 2. Press the [F6] button twice. The Dual mode settings screen appears. 3. Press the [-] [+] buttons to access the screen of the item you want to set. 4. Press the [F6] button so that "-" "+" is shown in the bottom line of the screen. 5. Press the [-] [+] buttons to select the value that you want to change.
Changing the octave of the left-hand tone and right-hand tone (Split-Left Shift / Split-Right Shift)	<ol style="list-style-type: none"> 1. Press the [F6] button. This switches to Keyboard mode. 2. Press the [F6] button twice. The Split mode settings screen appears. 3. Press the [-] [+] buttons to access the screen of the item you want to set. 4. Press the [F6] button so that "-" "+" is shown in the bottom line of the screen. 5. Press the [-] [+] buttons to select the value that you want to change.

MEMO

With the split screen shown, hold down the [F6] button and press a key to set the split point from the keyboard.

Layering Two Tones

You can play two tones simultaneously from a single key. This function is called "Dual Play".

1. Press the [F6] button.
2. Press the [-] [+] buttons to select "Keyboard Mode" and press the [F6] button.
3. Press the [-] [+] buttons to select "Dual".
4. Press the [F6] button to exit Keyboard mode.

The split screen appears.



When you turn on the power, "Concert Piano" is selected as the tone 1 and "SymphonicStr1" is selected as the tone 2.

5. To exit Dual Play, press the [F6] button to enter Keyboard Mode, and set "Keyboard Mode" to "Whole".

Changing the settings for Dual Play

To edit the following settings, access the Dual screen.

	Operation
Changing Tone 2 (Dual-Tone 2)	<ol style="list-style-type: none"> 1. Press the [F6] button so that "-" "+" is shown in the lowest line of the screen. 2. Press a tone button. The tone group is selected. 3. Press the [-] [+] buttons to select a tone.
Changing Tone 1 (Dual-Tone 1)	<ol style="list-style-type: none"> 1. Press the [F6] button so that "-" "+" is shown in the top line of the screen. 2. Press a tone button. The tone group is selected. 3. Press the [-] [+] buttons to select a tone.
Changing the volume balance of the two tones (Dual-Balance)	<ol style="list-style-type: none"> 1. Press the [F6] button. This switches to Keyboard mode. 2. Press the [F6] button twice. The Dual mode settings screen appears. 3. Press the [-] [+] buttons to access the screen of the item you want to set. 4. Press the [F6] button so that "-" "+" is shown in the bottom line of the screen. 5. Press the [-] [+] buttons to select the value that you want to change.
Changing the octave of the two tones (Dual-Tone1 Shift / Dual-Tone2 Shift)	<ol style="list-style-type: none"> 1. Press the [F6] button. This switches to Keyboard mode. 2. Press the [F6] button twice. The Split mode settings screen appears. 3. Press the [-] [+] buttons to access the screen of the item you want to set. 4. Press the [F6] button so that "-" "+" is shown in the bottom line of the screen. 5. Press the [-] [+] buttons to select the value that you want to change.

Instantly recalling the Grand Piano tone


Long-press the [F6] button to cancel Split Play or Dual Play and recall the Grand Piano (Concert Piano) tone.

Playing in a Different Key (Transpose)

You can transpose the keyboard in semitone steps.

For instance, if you wanted to play a song in the key of C that was written in the key of E, set the keyboard transpose value to "4".

When you play "C-E-G", you hear "E G# B"



1. Press the [] button.
2. Press the [-] [+] buttons to select "Kbd Transpose".
3. Press the [] button.
4. Press the [-] [+] buttons to select a value.


Value	Explanation
-6-0-5 (default value: 0)	

5. Press the [] button to exit Keyboard mode.

Reading the note name (e.g., C4)

The alphabetical indication for settings such as "split point" shows the name of the note. The solfège equivalents are as follows: A is "la", B is "ti", C is "do", D is "re", E is "mi", F is "fa" and G is "so".

For example, the indication "C4" means "the fourth 'C' from the left edge of the keyboard".



Change the Key Touch (Key Touch)

You can change the playing feel (touch) of the keyboard.

1. Press the [] button.
2. Press the [-] [+] buttons to select "Key Touch".
3. Press the [] button.
4. Press the [-] [+] buttons to select a value.

Value	Explanation
Fix, 1-100 (default value: 50)	The default value of 50 provides a key touch that is closest to that of an acoustic piano. Higher settings make the keyboard feel heavier. With the "Fix", notes sound at a fixed volume regardless of how strongly you play the keyboard.

5. Press the [] button to exit Keyboard mode.

Adjusting the Time from When You Play the Key Until the Piano Is Heard (Hammer Response)

You can adjust the time from when you play the key until the piano sound is heard.

1. Press the [] button.
2. Press the [-] [+] buttons to select "Hammer Response".
3. Press the [] button.
4. Press the [-] [+] buttons to select a value.

Value	Explanation
Off, 1-10 (default value: 1)	Higher values produce a greater delay.


5. Press the [] button to exit Keyboard mode.

Registering Your Favorite Settings


You can register the settings you've adjusted to the way you like, and then switch between settings for each song or for different players.

Registering the current performance settings


1. Long-press the [] button.
The "Store Registration" screen appears.



2. Use the [1] [2] [3] [4] buttons and the [-] [+] buttons to select the registration number where you want to store the current settings, and press the [] button to execute.




3. Edit the name.



- a. Press the [-] [+] buttons to select the character to edit, and press the [] button to execute.
- b. Press the [-] [+] buttons to edit the character, and press the [] button to execute.
 - To insert a character, press the [] button.
 - To delete a character, press the [] button.

- Using the steps for editing a character, press the [-] [+] buttons to select ✓ on the right side of the screen, and press the [Enter] button to execute.



The Registration screen appears, and the settings you registered are shown.



MEMO


When you select "Start-up", you can register these settings as the settings used right when the instrument is turned on.

Recalling Your Favorite Settings


- Press the [F] button. This selects the registration group. The name of the currently selected registration is shown.
- Press the [1] [2] [3] [4] buttons.
- Press the [-] [+] buttons. This selects the settings within the registration group.

Initializing Your Favorite Settings

- Press the [F] button to display the registration settings screen, and then press the [1] [2] [3] [4] buttons and the [-] [+] buttons to select the registration to initialize.



- Long-press the [=] button. A confirmation message appears.



- Press the [-] [+] buttons to select "Yes", and press the [Enter] button to execute. This initializes the selected registration.

Practicing with the Metronome

You can practice while hearing a metronome.

MEMO

Change the metronome type to a rhythm pattern if you want to play along with the rhythm.

- Press the [M] button.

The [M] button blinks, and the metronome sounds.

MEMO

If a song is playing, the metronome sounds at the tempo and time signature of that song.

- To change the tempo, press the [J] button and then press the [-] [+] buttons to select the desired tempo.

You can change the tempo by pressing the [J] button and then using the [Enter] button to select the word that describes the tempo.

- To stop the metronome, press the [M] button once again.

The [M] button goes dark.

MEMO

If you press both [-] [+] buttons at the same time at the tempo setting screen, the tempo returns to that of the currently selected song (The tempo is set to 108 when you turn on the power.)

Changing the settings for metronome

Change the following settings while the [M] button is on. The setting that you can edit change depending on the metronome type settings.

	Operation	
Common	Change the metronome type (Metronome Type)	<ol style="list-style-type: none"> Press the [M] button and the [J] button at the same time so that "-" "+" is shown in the top line of the screen. Press the [-] [+] buttons to access the screen of the item you want to set. Press the [Enter] button so that "-" "+" is shown in the bottom line of the screen. Press the [-] [+] buttons to select the value that you want to change.
When the Metronome Type is "Metronome"	Change the time signature (Beat)	
	Play the metronome without emphasizing the downbeat (Metronome Downbeat)	
	Change the metronome pattern (Metronome Pattern)	
When the metronome type is "Rhythm Pattern"	Change the metronome volume (Metronome Volume)	
	Change the metronome tone (Metronome Tone)	
Available time signatures	2/2, 3/2, 2/4, 3/4, 4/4, 5/4, 6/4, 7/4, 3/8, 6/8, 8/8, 9/8, 12/8 (default value: 4/4)	

MEMO

The metronome or rhythm plays 6/8 as 2/2, 9/8 as 3/4, and 12/8 as 4/4.

Listening to Songs

Playing Back a Song

Here's how you can listen to the built-in songs. You can listen to these internal songs as models for your own playing, or practice one hand at a time along with them.


→ "Internal Song List" (p. 43)

Category list

Category	Explanation
Listening	Piano songs recommended for listening
Ensemble (*)	Famous songs, mainly classical pieces. These include piano concertos, duets, and jazz arrangements of classical pieces. Since this collection contains songs that are challenging to play, they are recommended for those at intermediate level or above.
Entertainment (*)	Arrangements of well-known songs from around the world, including pop, jazz, and children's songs, in arrangements that can be enjoyed by a wide range of people from the beginner to the advanced player.
Do Re Mi Lesson (*)	You can use these lessons to learn the basics of music, by singing solfège along with the songs or practicing score-reading.
Scales (*)	Scales in all keys (major scales, minor scales)
Hanon	The Virtuoso Pianist No.1-20
Beyer	Vorschule im Klavierspiel Op.101 No.1-106
Burgmüller	25 Études faciles et progressives Op.100
Czerny100	100 Übungsstücke Op.139
USB Memory	Songs saved on a USB flash drive
Internal Memory	Songs saved in internal memory

(*) Songs corresponding to the included collection of scores, "Roland Piano Masterpieces".

1. Press the [☐] button.
The Song screen appears.



2. Press the [-] [+] buttons to select a song category.
3. Press the [☐] button.
4. Press the [-] [+] buttons to select a song within a category.

MEMO

If you decide to select a different song category, press the [⇒] button.

5. Press the [▶/■] button.
The songs play back, with the [☐] button blinking in time with the tempo.
6. To stop the song, press the [▶/■] button once again.
The [▶/■] button goes dark.
7. To exit song settings, press the [☐] button.
The [☐] button goes dark.

Changing how songs play back

	Operation
Playing back individual performance parts	<p>The built-in songs consist of three parts (right-hand, left-hand, accompaniment), and you can play back just the part(s) that you want to hear.</p> <p>* Some songs don't have a left-hand part or an accompaniment part. In this case, you can't select the corresponding part.</p> <ol style="list-style-type: none"> 1. Press the [☐] button. 2. Press the [-] [+] buttons to select the part that you want to mute. 3. Press the [☐] button. The selected part is muted. 4. Press the [▶/■] button. Only the selected part(s) song play back.
Changing the song tempo	<ol style="list-style-type: none"> 1. Press the [♩=] button and then press the [-] [+] buttons. <p>MEMO Press both of the [-] [+] buttons at the same time to return to the default tempo value.</p>
Playing back the song at a constant tempo	<p>This is convenient when you want to practice along with the song playback.</p> <ol style="list-style-type: none"> 1. While holding down the [▶/■] buttons, press the [♩=] button. The message "Tempo Mute On" appears, and the song plays back at a fixed tempo. Press and hold down the [▶/■] button again, and then press the [♩=] button to return to the original tempo (the message "Tempo Mute Off" appears).
Selecting the measure to play back	<ol style="list-style-type: none"> 1. Follow steps 1-4 in "Playing Back a Song" (p. 17). 2. Press the [ö/ù] button. The measure screen appears. 3. Press the [-] [+] buttons to select how many measures to play. 4. Press the [ò] button. The song plays from the specified measure. <p>MEMO</p> <ul style="list-style-type: none"> • Press the [ò] button to select the beginning of the song. • Press the [č] button to return to the song select screen. • You can also press the [☐] button to begin playback.
Sounding a count before the song plays	<ol style="list-style-type: none"> 1. While holding down the [☐] button, press the [▶/■] button. The metronome button blinks in time with the tempo.
Playing all songs in the selected category	<ol style="list-style-type: none"> 1. While holding down the [☐] button, press the [▶/■] button. The [▶/■] button blinks, and the songs in the selected category play back in order.
Playing back in a different key	<ol style="list-style-type: none"> 1. Press the [✳] button. The [✳] button is lit, and the piano is in function mode. 2. Press the [-] [+] buttons to access the "Song Transpose" screen. 3. Press the [☐] button. 4. Press the [-] [+] buttons to select how far the pitch is to be transposed (the number of semitones). 5. Press the [▶/■] button. The song playback is transposed.

English

日本語

Deutsch

Français

Italiano

Español

Português

Nederlands

简体中文

Listening to Songs

	Operation
Playing songs from a folder on a USB flash drive	1. Press the [⏏] button.
	2. Press the [-] [+] buttons to display "USB Flash Drive".
	3. Press the [⏏] button.
	Enter the folder
	a. Press the [-] [+] buttons to select the desired folder.
	b. Press the [⏏] knob to confirm.
	Exit the folder
	a. Press the [-] [+] buttons to select "Up".
	b. Press the [⏏] knob to confirm.
	4. Press the play/stop button. The songs on the USB flash drive begin playing back.
	* Files with a file extension of ".WAV", ".MP3" or ".MID" can be played back.


Having Fun with the Moving Key Function

You can use the Moving Key function to make the keyboard automatically play along with the internal songs or songs you've recorded, or with the piano sounds in song data that was copied to a USB flash drive.

Precautions when using this feature

- The sound of the internal drive mechanism that operates the key action can be heard while Moving Key is in use. The quality and volume of sound may change as the mechanism is used over time.
- The sound produced by the piano may not always be in time with the automatic key action.
- The mechanism may not be able to accurately reproduce certain aspects of a performance, such as responding to quick changes in playing speed during a passage or playing the same key in quick succession.
- Do not prevent the keys from moving normally, such as by forcibly pressing on keys while the Moving Key function is in use or by forcibly lifting up keys that are pressed down. Doing so may cause a malfunction.

Making the Keys Play Along with the Internal Songs or Songs You've Recorded, or with Song Data Copied to a USB Flash Drive

- 1. Press the [✳] button.**
The [✳] button is lit, and the piano is in function mode.
 - 2. Press the [-] [+] buttons to access the "Moving Key" screen, and then press the [⏏] button.**
The Moving Key On/Off setting screen appears.
 - 3. Press the [⏏] knob to confirm.**
- 
- If you decide to cancel, press the [⇒] button.
- 4. Press the [-] [+] buttons to select "On", and press the [⏏] button to execute.**
This turns the Moving Key function on.
 - 5. Follow the steps in "Listening to Songs" (p. 17) to play back a song.**
The keys move automatically in time with the piano part.

MEMO

To play back all songs within a category, press the [⏏] button while holding down the [▶/■] button.

Selecting the part played by Moving Key

This shows how to select the part (MIDI channel) containing the piano sound that's used to make the keyboard play.

- 1. Press the [✳] button.**
The [✳] button is lit, and the piano is in function mode.
- 2. Press the [-] [+] buttons to access the "Moving Key" screen, and then press the [⏏] button.**
The Moving Key On/Off setting screen appears.
- 3. Press the [-] [+] buttons to access the "Moving Key Ch." screen, and then press the [⏏] button.**



- 4. Press the [-] [+] buttons to select the piano part (MIDI channel) to be played by Moving Key, and press the [⏏] button to confirm.**


Value	Explanation
Auto (default setting)	Automatically detects which channel is used to make the keyboard play, based on the sound settings in the song.
3&4	Sets the MIDI channels to channels 3 and 4, which are used to make the keyboard play. * The internal songs and the piano parts recorded on this instrument were recorded using MIDI channels 3 and 4.
1-16	Specifies the channel used to make the keyboard play.

Using the Roland Piano App to Play the Keyboard Along with a Song


You can use the app ("Roland Piano App" by Roland) (p. 29) installed on your mobile device to play back songs, and enjoy watching and hearing the songs automatically played back on the piano keyboard.

* In the case of "using the piano with an app", settings on the piano are not necessary. Perform operations in the app to pair it with the piano.

- 1. Launch Roland Piano App.**
- 2. Tap "GP-9M MIDI".**




A connection screen is shown, and your mobile device is connected to the piano via **Bluetooth**.




Having Fun with the Moving Key Function

3. Once the “Connected!” screen appears, tap “Done”.




4. On the home screen of the app, tap “Library”.



5. Tap the category of the song you want to play back.


6. Tap the song you want to play back.










7. Once the sheet music for song is shown, press the play button to play back the song.



< Ballade No.1 ♥
Fryderyk Franciszek Chopin

1 2 3 4
5 6 7 8
9 10 11 12
13 14 15 16


Record 


Making the Keyboard Play Along with Commercially Available Data

You can also make the keyboard play along with commercially available data (player piano data) that's saved on your smartphone, computer or USB flash drive.

Connecting the devices



Bluetooth Audio connection (p. 28)




NOTE

When using commercially-available player piano data with Moving Key, multiple inputs can't be used at the same time.

Setting the Type of Data to Play Back

Some types of commercially-available player piano data can't be correctly read by this piano. If the keys aren't moving correctly, you can use the steps below to specify the data type.

1. Press the [F] button.
The [F] button is lit, and the piano is in function mode.
2. Press the [-] [+] buttons to access the "Player Piano Setting" screen, and then press the [Enter] button.
3. Press the [-] [+] buttons to access the "Player Piano Mode" screen, and then press the [Enter] button.



4. Press the [-] [+] buttons to select the value.

Parameter	Value	Explanation
Player Piano Mode	Auto (default setting)	The data type is automatically determined.
	TypeA	Generally, player piano data contains both audio and MIDI data, so the data format depends on the data content. The piano makes a beeping noise if the data format doesn't match the settings on this instrument. Some player piano data can't be played back.
	TypeB	
	Off	Plays back the data as regular audio data.

* With the "Auto" setting, it may take time for the piano to determine the data type, and the intro part of the song may get cut off. If you aren't using commercially available data, we recommend that you set this to "Off"

* If this does not work correctly, use either the "TypeA" or the "TypeB" setting.


Note

Some commercially available data can't be played back.

Adjusting the Accompaniment Level

You can adjust the volume of the accompaniment.

1. Press the [F] button.
The [F] button is lit, and the piano is in function mode.
2. Press the [-] [+] buttons to access the "Player Piano Setting" screen, and then press the [Enter] button.
3. Press the [-] [+] buttons to access the "Audio Level" screen, and then press the [Enter] button.




4. Press the [-] [+] buttons to select the value.

Parameter	Value
Audio Level	0-10 (default value: 7)

Matching the Timing of the Piano Sound with the Accompaniment

With some data, the piano sound may get out of time with the accompaniment sound. If this happens, you can adjust the timing of the piano sound to make it match the accompaniment.

1. Press the [F] button.
The [F] button is lit, and the piano is in function mode.
2. Press the [-] [+] buttons to access the "Player Piano Setting" screen, and then press the [Enter] button.
3. Press the [-] [+] buttons to access the "Audio Sync" screen, and then press the [Enter] button.



4. Press the [-] [+] buttons to select the value.

Parameter	Value
Audio Sync	-10-0-+10 (default value: 0)

Stopping the Moving Key Performance and Sound for the Piano Part

1. Press the [✳] button.
The [✳] button is lit, and the piano is in function mode.
2. Press the [-] [+] buttons to access the “Player Piano Setting” screen, and then press the [↵] button.
3. Press the [-] [+] buttons to access the “Piano Mute” screen, and then press the [↵] button.



4. Press the [-] [+] buttons to select “On”.

Parameter	Value
Piano Mute	Off, On (default value: Off)

Regular maintenance

As the Moving Key mechanism performs over time, the drive mechanism and key sensors may eventually wear out. The mechanism may require regular maintenance. Please inquire with Roland support for assistance.

When maintenance should be required

Key sensors	These may need to be replaced around once a year.
Drive mechanism	This may need to be replaced around once every two years.

* These figures may change greatly, depending on the environment in which the piano is used.

How to prolong the life of these mechanisms

- Turn Moving Key off if you are not using it.
- Set “Moving Key Ch.” to “Auto”.
- Use the piano in a room temperature of 20–25°C.

Recording Your Performance

Recording Your Keyboard Performance

You can record your own keyboard performance, and then play it back to hear how you did.

Getting Ready to Record

1. Select the tone that you want to play.
2. You can sound the metronome if you like.
Set the metronome's tempo and time signature. The metronome setting is stored in the song, and you can use the same settings during playback.
3. Press the [●] button.
The [●] button lights, the [▶/■] button blinks, and the piano enters record-standby mode.
If you decide to cancel recording, press the [●] button once again.

Starting/Stopping Recording

4. Press the [▶/■] button.
After a one-measure count, recording starts, and the [●] button and [▶/■] button are both lit. The performance is saved automatically.

MEMO

You can also start recording by playing the keyboard instead of pressing the [▶/■] button. In this case, a count is not sounded.

5. To stop recording, press the [▶/■] button once again.
Recording stops.

Listening to the Recorded Performance

6. Press the [▶/■] button.
After you record, the newly recorded song is selected.
The recorded song starts playing back.

Deleting a Saved Song

You can delete a song that you saved.

MEMO

- You can also delete a recorded song by holding down the [●] button and pressing the [↵] button.
- If you want to delete all songs that have been saved to internal memory, initialize the memory ("Initializing the Memory (Format Media)" (p. 32)).

1. Press the [✳] button.
The [✳] button is lit, and the piano is in function mode.
2. Press the [-] [+] buttons to access the "Delete Song" screen.
3. Press the [↵] knob to confirm.
The Delete Song screen appears.



4. Press the [-] [+] buttons to select the media where the data is saved, and press the [↵] knob to confirm.

5. Press the [-] [+] buttons to select the song to delete, and press the [↵] knob to confirm.

A confirmation message appears.



If you decide to cancel, press the [↵] button.

6. Press the [-] [+] buttons to select "Yes", and press the [↵] button to execute.

The deletion is executed.

- * Never turn off the power or disconnect the USB flash drive while the screen indicates "Executing...".
- * Never turn off the power, disconnect the USB flash drive or unplug the power cord while the indicator of GP-9M shows that an operation is in progress.

Managing songs you recorded

Operation		
	You can rename a saved song.	
	<ol style="list-style-type: none"> 1. Press the [✳] button. The [✳] button is lit, and the piano is in function mode. 2. Press the [-] [+] buttons to access the "Rename Song" screen, and press the [↵] button to confirm. 3. Press the [-] [+] buttons to select the media that contains the song you want to rename, and press the [↵] button to confirm. 4. Press the [-] [+] buttons to select the song that you want to rename, and press the [↵] button to confirm. Rename the song. 	
Renaming a recorded song	Select the character which you want to change	Press the [-] [+] buttons
	Change the character	Press the [↵] button (confirm) → Press the [-] [+] buttons (edit character) → Press the [↵] button (back)
	Insert one character	Press the [▶/■] button
	Delete one character	Press the [●] button
	<ol style="list-style-type: none"> 5. Press the [-] [+] buttons to select ✓ on the right side of the screen, and press the [↵] button to execute. A confirmation message appears. 6. Press the [-] [+] buttons to select "Yes", and press the [↵] button to execute. The song is renamed. <ul style="list-style-type: none"> * Never turn off the power, disconnect the USB flash drive or unplug the power cord while the screen indicates "Executing...". <ol style="list-style-type: none"> 7. Press the [✳] button. You exit function mode. 	

English

日本語

Deutsch

Français

Italiano

Español

Português

Nederlands

简体中文

	Operation
Copying a recorded song	Songs that have been saved in internal memory can be copied to USB flash drive. Alternatively, songs stored on a USB flash drive can be copied to internal memory.
	1. Press the [☼] button. The [☼] button is lit, and the piano is in function mode.
	2. Press the [-] [+] buttons to access the "Copy Song" screen, and press the [☑] button to confirm.
	3. Press the [-] [+] buttons to select the copy source and destination media, and press the [☑] knob to confirm.
	4. Press the [-] [+] buttons to select the song that you want to copy. If you decide to cancel, press the [⇒] button.
	5. Press the [☑] button. The copy is executed. * Never turn off the power, disconnect the USB flash drive or unplug the power cord while the screen indicates "Executing...".
6. Press the [☼] button. You exit function mode. * The audio data can't be copied.	

Advanced Recording Methods

Recording Your Performance One Hand at a Time

By recording your left-hand performance to the Left part and your right-hand performance to the Right part, you can record each hand of your performance separately.



Left (or right) part

Getting ready to record

- 1. Select the tone that you want to play.**
- 2. You can sound the metronome if you like.**
Set the metronome's tempo and time signature. The metronome setting is stored in the song, and you can use the same settings during playback.
- 3. Press the [●] button.**
The [●] button lights, the [▶/■] button blinks, and the piano enters record-standby mode.
If you decide to cancel recording, press the [●] button once again.
- 4. Press the [🎹] button, press the [-] [+] buttons to select the part that you don't want to record, and then press the [☑] button to make it go dark.**
Only the part that you're recording will blink.

MEMO

If you don't select a part at this time, your performance is recorded to the following parts.

Performing with one tone	"Right" part
Playing different tones with the left and right hand (Split Play)	The left-hand tone is the "Left" part, and the right-hand tone is the "Right" part
Performing with two tones layered (Dual Play)	The tone 1 is the "Right" part, and the tone 2 is the "Accomp" part

Starting/stopping recording

- 5. Press the [▶/■] button.**
After a one-measure count, recording starts, and the [●] button and [▶/■] button are both lit. The performance is saved automatically.

MEMO


You can also start recording by playing the keyboard instead of pressing the [▶/■] button. In this case, a count is not sounded.

- 6. To stop recording, press the [▶/■] button once again.**
Recording stops.

Overdubbing a Recorded Performance

After recording one hand of your performance, you can overdub-record the performance of the other hand.

You can also overdub-record onto a built-in song.



Getting ready to record

1. Press the [RECORD] button.

The Song screen appears.

MEMO

If the measure screen appears, press the [RETURN] button to return to the song-select screen.

2. Press the [-] [+] buttons to select the category of the song that you want to overdub, and press the [ENTER] button to confirm.

3. Press the [-] [+] buttons to select the song that you want to overdub.

You can select songs within the category.

MEMO

If you're recording your performance along with a built-in song, you can fix the tempo of the built-in song (p. 17).


4. Press the [STOP] button.

The [STOP] button lights, the [PLAY/PAUSE] button blinks, and the piano enters record-standby mode.

If you decide to cancel recording, press the [STOP] button once again.

5. Press the [-] [+] buttons to access the "Overdub" screen.

The song of step 3 is selected.



6. Press the [RECORD] button. If a part that you don't want to record is blinking, press the [-] [+] buttons to select the part, and press the [ENTER] button to make it go dark.

Only the part that you're recording will blink.

If you select a part that is already recorded (lit) and then press the [RECORD] button to make it blink, that part will be overwrite-recorded.

Starting/stopping recording

7. Press the [PLAY/PAUSE] button.

After a one-measure count, recording starts, and the [STOP] button and [PLAY/PAUSE] button are both lit. The performance is saved automatically.

MEMO


You can also start recording by playing the keyboard instead of pressing the [PLAY/PAUSE] button. In this case, a count is not sounded.

8. To stop recording, press the [PLAY/PAUSE] button once again.

Recording stops.

Recording Audio to USB Flash Drive

If you audio-record your performance, you'll be able to listen to it on your computer or audio player, use it to create a music CD, or publish it on the internet.



Getting ready to record

1. Connect your USB flash drive to the USB Memory port.

- * Audio data can't be saved in the piano's internal memory.
- * Never turn off the power or disconnect the USB flash drive while the screen indicates "Executing...".
- * Never turn off the power or disconnect a USB flash drive or the power cord while the USB flash drive access indicator is blinking.

2. Select the tone that you want to play.

3. Hold down the [STOP] button and press the [-] [+] buttons to select "Audio".

MEMO

You can also specify this via the Function mode "Recording Mode" setting (p. 34).

4. Press the [STOP] button.

The [STOP] button lights, the [PLAY/PAUSE] button blinks, and the piano enters record-standby mode.

If you decide to cancel recording, press the [STOP] button once again.

5. You can sound the metronome if you like.

Starting/stopping recording

6. Press the [PLAY/PAUSE] button.

Recording starts, and the [STOP] button and [PLAY/PAUSE] button are lit. The performance is saved automatically.

NOTE

Never turn off the power or disconnect the USB flash drive during recording.

7. To stop recording, press the [PLAY/PAUSE] button once again.

Recording stops.

- * Never turn off the power or disconnect the USB flash drive while the screen indicates "Executing...".
- * Never turn off the power or disconnect a USB flash drive or the power cord while the USB flash drive access indicator is blinking.

MEMO

- You can delete the song that you recorded (p. 23).
- You can rename the song that you recorded (p. 23).

Creating Your Own Piano Tone (Piano Designer)

This piano lets you adjust various elements of the sound, so you can personalize the piano tone to your taste.

This function is called “Piano Designer”.

MEMO

The process of creating your own piano tone can also be done using touch operations on the dedicated app.

→ “Using the Piano with an App” (p. 29)



App “Piano Designer”



Adjusting the Sound of the Overall Piano

1. Press the [X] button.
2. Press the [-] [+] buttons to access the screen of the item that you want to adjust.
3. Press the [⊞] knob to confirm.
4. Press the [-] [+] buttons to select the value.
5. To exit the settings, press the [X] button.
The [X] button goes dark.

Items	Value	Explanation
Master Tuning	415.3 Hz–466.2 Hz (default value: 442.0 Hz)	When playing in an ensemble with other instruments, you can adjust the reference pitch of this piano so that you will harmonize correctly with the other instruments. The reference pitch is usually expressed as the frequency that is heard when you play the middle A (A4) note. The action of matching the reference pitch to other instruments is called “tuning”.
Temperament	You can play classical styles such as Baroque using historic temperaments (tuning methods). Most modern songs are composed for and played in equal temperament, the most common tuning in use today. But at one time, there were a wide variety of other tuning systems in existence. By playing in the temperament that was in use when a composition was created, you can experience the sonorities of chords originally intended for that song.	
	Equal (default setting)	This temperament divides the octave into twelve equal steps. It is the temperament that is most commonly used on today’s pianos. Every interval has the same slight amount of dissonance.
	Just Major	In these temperaments, the primary triads are perfectly consonant. It is unsuited to playing melodies and cannot be transposed, but is capable of beautiful sonorities. The Just tunings differ from major and minor keys.
	Just Minor	
	Pythagorean	This tuning, devised by the philosopher Pythagoras, eliminates dissonance in fourths and fifths. Although triadic chords are slightly dissonant, this tuning is suitable for songs that have a simple melody.
	Kirnberger I	Kirnberger I. As in the Just temperaments, the primary triads are consonant in this tuning. Beautiful sonorities are obtained when playing songs that are written in keys appropriate for this tuning.
	Kirnberger II	Kirnberger II. This is a revision of Kirnberger I that reduces the limitations on the usable keys.
	Kirnberger III	Kirnberger III. This is an improvement of the Meantone and Just tunings that provides a high degree of freedom of modulation. Performances are possible in all keys. Since the resonance differs depending on the key, chords played in this temperament resonate in diverse ways when compared to equal temperament.
	Meantone	This temperament slightly narrows the fifth relative to Just temperaments. While the Just temperaments contains two types of whole tone (major whole tone and minor whole tone), meantone temperament uses only one type of whole tone (mean whole tone). Transposition within a limited range of keys is possible.
	Werckmeister	Werckmeister. This temperament consists of eight perfect fifths and four narrowed fifths. Performances are possible in all keys. Since the resonance differs depending on the key, chords played in this temperament resonate in diverse ways when compared to equal temperament.
Arabic	This tuning is suitable for the music of Arabia.	
Temperament key	C–B (default value: C)	This sets the primary key of the temperament. When playing with tuning other than equal temperament, you need to specify the temperament key for tuning the song to be performed (that is, the note that corresponds to C for a major key or to A for a minor key). If you choose an equal temperament, there’s no need to select a temperament key.

Editing the Grand Piano Tone


You can adjust various aspects of the grand piano's tone, including the string and pedal resonances, and the sound of the hammers striking the strings.

* Only tones belonging to the "Grand" group can be adjusted.

1. Press the [F] button.
2. Press the [-] [+] buttons to access the "Piano Tone Edit" screen.
3. Press the [Enter] knob to confirm.
4. Press the [-] [+] buttons to access the screen of the item that you want to adjust.
5. Press the [Enter] button to confirm, and press the [-] [+] buttons to select the value of the setting.

6. When you are finished editing the piano tone, press [Enter] button.

A confirmation message appears.



If you decide to cancel, press the [Enter] button.

7. Press the [-] [+] buttons to select "Yes", and press the [Enter] button to execute.

The Grand Piano tone settings are saved.

	Items	Value	Explanation
Piano Tone Edit	Lid	0-6 (default value: 4)	Adjusts the extent to which the top lid of the grand piano is open. The sound will become more mellow as you close the top lid of the piano in the screen. The sound will become brighter as you open the top lid of the piano in the screen.
	Key Off Noise	Off, 1-10 (default value: 3)	Adjusts the action noise that is heard when you release a key. Higher settings produce a louder action noise.
	Hammer Noise	-5-0-+5 (default value: 0)	Adjusts the sound produced when the hammer of an acoustic piano strikes the string. Higher settings will produce a louder sound of the hammer striking the string.
	Duplex Scale	Off, 1-10 (default value: 2)	Adjusts the sympathetic vibrations of an acoustic piano's Duplex Scale. Higher settings will make the sympathetic vibration louder. The Duplex Scale is a system of sympathetically vibrating strings sometimes included in grand pianos. These sympathetically vibrating strings are not struck directly with hammers, but sound by vibrating in sympathy with the vibrations of other strings. By resonating with the overtones, these strings add richness and brilliance to the sound. These sympathetic strings are added only to the high register above approximately C4. Since they do not have a damper (a mechanism that stops them from sounding), they will continue sounding even after you play a note and then release it to stop the sound of the string that was actually struck.
	Full Scale String Res.	Off, 1-10 (default value: 4)	Adjusts the resonant sound of an acoustic piano (the sound produced by the strings of previously-pressed keys vibrating in sympathy with newly played notes, or the sound of other strings vibrating in sympathy with the notes you play while pressing the damper pedal). Higher settings produce louder sympathetic resonance.
	Key Off Resonance	Off, 1-10 (default value: 3)	Adjusts the resonance of the subtle sounds that occur when a key of an acoustic piano is released. A higher value produces a larger tonal change during the decay.
	Cabinet Resonance	Off, 1-10 (default value: 4)	Adjusts the body resonance of the grand piano itself. Higher values will produce a larger body resonance.
	Soundboard Type	1-5 (default value: 1)	Selects how the soundboard of the acoustic piano will resonate. You can choose from five different types of resonance.
	Damper Modeling	Off, 1-10 (default value: 5)	Adjusts the damper noise of the acoustic piano sound (the sound of the damper releasing the strings when you press the damper pedal).
	Soft Pedal	1-10 (default value: 2)	Adjusts the depth of the effect that occurs when you press the soft pedal. With higher values, the change will be greater.
	Single Note Tuning (*1)	-50.0-0-+50.0 (per key)	Adjusts the tuning of each individual key. For example, you can adjust the width of stretched tuning, which tunes the higher register slightly higher and the lower register slightly lower.
	Single Note Volume (*1)	-50-0 (per key)	Adjusts the volume of each key. Lower settings decrease the volume.
	Single Note Character (*1)	-5-0-+5 (per key)	Adjusts the tonal character of each key. Higher settings produce a harder sound, and lower settings produce a softer tone. * The result of this effect will differ depending on the pitch range.
Reset Setting	Resets the "Piano Tone Edit" settings of the selected tone to their factory settings.		

(*1) Single Note settings

1. Select the Single Note settings screen, and press the [Enter] button to confirm.
2. Press the key on the keyboard that you want to select, and press the [-] [+] buttons to edit the value.

3. Press the [Enter] button to exit the screen of that item.

English

日本語

Deutsch

Français

Italiano

Español

Português

Nederlands

简体中文

Connecting the Piano and a Mobile Device via **Bluetooth®**




Here's What You Can Do

Bluetooth functionality creates a wireless connection between a mobile device such as a smartphone or tablet (subsequently referred to as "mobile device") and the piano, letting you do the following.

→ Play Music Through the Piano's Speakers

page 28


Music data stored on your mobile device can be played wirelessly through the piano's speakers.



→ Using the Piano with an App

page 29

Install the app ("Roland Piano App" by Roland) on your mobile device to exchange data with the piano.



App "Roland Piano App"

Play Music Through the Piano's Speakers

Here's how to configure the settings so that music data saved on your mobile device can be played wirelessly through the piano's speakers.

* Once a mobile device has been paired with the piano, there is no need to pair again. Refer to "Connecting an Already-Paired Mobile Device" (p. 29).

Initializing the Settings (Pairing)

This example shows how to configure the settings for iOS/iPadOS devices. If you are using an Android device, refer to the instructions for settings in the owner's manual that came with your mobile device.

1. Place the mobile device that you want to connect near the piano.
2. Press the [⊕] button.
The [⊕] button is lit, and the piano is in function mode.
3. Press the [-] [+] buttons to access the "Bluetooth" screen, and press the [⏏] button to confirm.

The following screen appears.



4. Press the [⏏] knob to begin pairing.




If you decide to cancel pairing, press the [⏏] button.

MEMO

Long-press the [⊕] button to start pairing immediately.

5. Turn on the **Bluetooth** function of the mobile device.




Pairing

To use **Bluetooth**, you must first "pair" the piano with your mobile device to create a one-to-one connection between them.


"Pairing" is the procedure of registering (mutually authenticating) your mobile device with the piano.

Pair the devices by following the steps shown for each function.



The pairing process

Separate pairing is required for "playing music through the piano's speakers" and for "using the piano with an app". Note that these processes are different.



6. Tap “GP-9M Audio” that appears in the mobile device’s Bluetooth “DEVICES” field.

The piano and mobile device are paired. When pairing is completed, a display like the following appears.

Mobile device	“GP-9M Audio” is added in the “My Devices” field
Piano	The screen indicates “Completed”, and “AUDIO” is shown beside the Bluetooth symbol



7. Press the piano’s [⊗] button to exit function mode.

Pairing is complete.

Playing back audio

When you play back music data on the mobile device, the sound is heard from the piano’s speakers.

MEMO

To adjust the volume of the audio, make adjustments on your mobile device. If this does not produce the desired volume, you can adjust the piano’s settings.

→ “Adjusting the Volume of Bluetooth Audio (Bluetooth Volume)” (p. 33)

Connecting an Already-Paired Mobile Device



1. Turn on the Bluetooth function of the mobile device.

The piano and mobile device are connected wirelessly.

* If the above step does not establish a connection, tap “GP-9M Audio” that is shown in the “DEVICES” field of the mobile device.

Using the Piano with an App

Apps You Can Use with This Piano

App name	Supported OS	Explanation
 Roland Piano App	iOS/iPadOS/ Android	This app lets you view sheet music in digital form, practice songs as if you were playing a game, or keep a record of your practicing.
 Piano Designer	iOS/iPadOS/ Android	This app lets you customize the piano sound to your taste. You can use the “Piano Designer” (p. 26) to adjust the various elements of the sound via touch-based editing within the app.

* Apps can be downloaded from the App Store (iOS/iPadOS products) or from Google Play (Android products).

* In addition to the above, you can also use music apps (such as Garage Band) that are compatible with **Bluetooth MIDI**.


* The information provided about apps made by Roland was current when this manual was published. For the latest information, refer to the Roland website.

Making the Settings (Pairing)

You can make settings for using the piano together with an app that’s installed on your mobile device. This shows the steps for using the “Roland Piano App” with the iPad as an example.

* In the case of “using the piano with an app”, settings on the piano are not necessary. Perform operations in the app to pair it with the piano.

1. Turn on the Bluetooth function of the mobile device.




NOTE

Even if the “DEVICES” field shows the name of the device you’re using (such as “GP-9M MIDI”), do not tap it.

2. Start the app that you installed on your mobile device.

3. Tap “Connection” at the top of the app screen, and tap “Connect to Piano”.




“GP-9M MIDI” is shown in the app screen.

4. Tap “GP-9M MIDI” (the name of the unit that you’re using).

The piano and mobile device are paired. When pairing is completed, a display like the following appears.

Mobile device	“GP-9M MIDI” is added in the “My Devices” field
Piano	The “MIDI” is shown beside the Bluetooth symbol



This completes the settings.

- English
- 日本語
- Deutsch
- Français
- Italiano
- Español
- Português
- Nederlands
- 简体中文

If Pairing Doesn't Work

If the pairing process shown in "Using the Piano with an App" (p. 29) is not successful, try steps 1–4 as shown below.

1 Make sure that the piano's Bluetooth function is "On"

1. Press the piano's [⊛] button.
The [⊛] button is lit, and the piano is in function mode.
2. Press the [-] [+] buttons to access the "Bluetooth" screen, and press the [⏏] knob to confirm.
You enter the Bluetooth setting screen.
3. Press the [-] [+] buttons to access the "Bluetooth On/Off" screen, and press the [⏏] button to confirm.
4. Press the [-] [+] buttons to select "On".
The piano's Bluetooth function turns on.
5. Press the [⊛] button.
The [⊛] button goes dark, and you exit function mode.

2 Exit all apps on your mobile device

Closing the app

1. Swipe up from the bottom of the home screen, stopping your finger around the middle of the screen. Next, swipe the app screen up.




* The method for closing apps may differ depending on your mobile device. Use the method that's appropriate for your device to close the apps.


3 If already paired, cancel pairing, and turn off the Bluetooth function

Clearing the pairing

1. In the mobile device's screen, tap the "i" located beside "Connected", and tap "Forget This Device".



2. Turn the Bluetooth switch off.



4 Restart your mobile device

5 Perform the pairing procedure of p. 29 from step 1

MEMO

If you've checked these points and the problem still occurs, please refer to the Roland support website.

<https://www.roland.com/support/>

If you have more than one piano

When pairing with a mobile device in a situation where there are multiple pianos, such as in a music classroom, you can assign an ID to each piano.

Assigning an ID

When you make this setting, an ID number is added to the end of the device name that's shown on the mobile device. (such as "GP-9M Audio 1" "GP-9M MIDI 1")

1. Press the [⊛] (Function) button.
2. Press the [-] [+] buttons to access the "Bluetooth" screen, and press the [⏏] knob to confirm.
3. Press the [-] [+] buttons to select "Bluetooth ID".
4. Press the [⏏] button to confirm, and press the [-] [+] buttons to change the number.

ID	Explanation
0-99	Set to "0": "GP-9M Audio""GP-9M MIDI" (default setting) Set to "1": "GP-9M Audio 1""GP-9M MIDI 1"

* If you are pairing in an environment where there are multiple pianos, we recommend that you turn on the power of the mobile device and only those pianos that you want to pair (turn off the power of other devices).

Convenient Functions

Loading/Saving Your Favorite Settings and Piano Setups

You can save your favorite settings or the piano's setup to a USB flash drive, or load these settings that are saved to a USB flash drive into the piano.

* Settings can be loaded only into another piano of the same model.

Piano settings that are saved

Setting	Page
Speaker volume	p. 12
Headphone volume	p. 12
Ambience Type	p. 13
Ambience Depth	p. 13
Key Touch	p. 15
Brilliance	p. 13
Master Tuning	p. 26
Temperament	p. 26
Temperament Key	p. 26
Hammer Response	p. 15
Piano Tone Edit	p. 27
Volume Limit	p. 35

* For the favorite settings that are saved, refer to the list of favorite settings as shown in "Settings Saved Even If the Power Is Turned Off" (p. 9).

Saving Your Favorite Settings and Piano Setups (Registration Export/Piano Setup Export)

1. Connect your USB flash drive to the USB Memory port.
2. Press the [F] button.
The [F] button is lit, and the piano is in function mode.
3. Press the [-] [+] buttons to show either the "Registration Export" or "Piano Setup Export" screen, and then press the [Enter] button to confirm.
The Registration or Piano Setup Export screen appears.



4. Edit the name of the registration or the piano setup.

Select the character which you want to change	Press the [-] [+] buttons
Change the character	Press the [Enter] button (confirm) → press the [-] [+] buttons (edit character) → press the [Enter] button (back)
Insert one character	Press the [▶/■] button
Delete one character	Press the [●] button

5. Press the [-] [+] buttons to select ✓ on the right side of the screen, and press the [Enter] button to execute.
The settings are saved.

NOTE

Never turn off the power, disconnect the USB flash drive or unplug the power cord while the screen indicates "Executing...".

6. Press the [F] button to exit function mode.
The [F] button goes dark.


* Never turn off the power, disconnect the USB flash drive or unplug the power cord while the indicator of GP-9M shows that an operation is in progress.

Loading Your Favorite Settings and Piano Setups (Registration Import/Piano Setup Import)

1. Connect your USB flash drive to the USB Memory port.
2. Press the [F] button.
The [F] button is lit, and the piano is in function mode.
3. Press the [-] [+] buttons to show either the "Registration Import" or "Piano Setup Import" screen, and then press the [Enter] button to confirm.
The Registration or Piano Setup Import screen appears.



4. Press the [-] [+] buttons to select either Registration Import or Piano Setup Import.
5. Press the [Enter] button to confirm.
A confirmation message appears.



If you decide to cancel, press the [Enter] button.

6. Press the [-] [+] buttons to select "Yes", and press the [Enter] button to execute.
This loads the settings.

NOTE

Never turn off the power, disconnect the USB flash drive or unplug the power cord while the screen indicates "Executing...".

7. Press the [F] button to exit function mode.
The [F] button goes dark.

* Never turn off the power, disconnect the USB flash drive or unplug the power cord while the indicator of GP-9M shows that an operation is in progress.

* When you load favorite settings (registration) for which the start-up settings have been changed, the unit switches to those settings right after the power is turned on.

English

日本語

Deutsch

Français

Italiano

Español

Português

Nederlands

简体中文

Initializing the Memory (Format Media)

Here's how to erase all of the files that you saved in internal memory or on a USB flash drive (commercially available).

NOTE

- When you initialize, all registrations or files that you saved in internal memory or on a USB flash drive are lost.
- If you want settings other than the memory settings to be returned to their factory-set state, execute a Factory Reset (p. 32).

1. If you want to initialize a USB flash drive, connect the USB flash drive to the USB Memory port.

2. Press the [⊛] button.

The [⊛] button is lit, and the piano is in function mode.

3. Press the [-] [+] buttons to access the "Format Media" screen, and then press the [↵] button to confirm.

The Format Media screen appears.




If you decide to cancel, press the [↵] button.

4. Press the [-] [+] buttons to select the media (Internal Memory or USB Memory) that you want to format.

5. Press the [↵] button to confirm.

A confirmation message appears.



If you decide to cancel, press the [↵] button.

6. Press the [-] [+] buttons to select "Yes", and press the [↵] button to execute.

This formats the media.

NOTE

Never turn off the power, disconnect the USB flash drive or unplug the power cord while the screen indicates "Executing...".

7. Press the [⊛] button to exit function mode.

The [⊛] button goes dark.

- * Never turn off the power, disconnect the USB flash drive or unplug the power cord while the indicator of GP-9M shows that an operation is in progress.

Restoring the Factory Settings (Factory Reset)

Here's how to restore all registrations and internally saved settings to the factory-set condition. This function is called "Factory Reset".

NOTE

Factory Reset erases all settings that you have stored, and returns them to the factory-set condition. For details on the settings that are reset, refer to "Settings Saved Even If the Power Is Turned Off" (p. 9).

MEMO


Executing this function does not erase the files in internal memory or on a USB flash drive (commercially available). If you want to erase all files from internal memory or from a USB flash drive, refer to ("Initializing the Memory (Format Media)" (p. 32)).

1. Press the [⊛] button.

The [⊛] button is lit, and the piano is in function mode.

2. Press the [-] [+] buttons to access the "Factory Reset" screen, and then press the [↵] button.

A confirmation message appears.



If you decide to cancel, press the [↵] button.

3. Press the [-] [+] buttons to select "Yes", and press the [↵] button to execute.

This performs the factory reset.

NOTE

Never turn off the power, disconnect the USB flash drive or unplug the power cord while the screen indicates "Executing...".

4. When the display indicates "Power off, then on", turn the power off and then on again.

- * Never turn off the power, disconnect the USB flash drive or unplug the power cord while the indicator of GP-9M shows that an operation is in progress.

Configuring the Various Settings

Function Mode

Basic Settings in Function Mode

1. Press the [**F**] button.
The [**F**] button is lit, and the piano is in function mode.
2. Press the [-] [+] buttons to access the screen of the item you want to set.
3. Press the [**Y**] knob to confirm.
* Depending on the item you select, there might be another screen for selecting additional items.
4. Press the [-] [+] buttons to select the value.
5. Press the [**F**] button to exit function mode.
The [**F**] button goes dark.

Indication	Value	Explanation
Bluetooth-related settings		
Bluetooth	Bluetooth On/Off	<p>Turning the Bluetooth Function On/Off (Bluetooth On/Off)</p> <p>If the Bluetooth function is on, you'll be able to wirelessly connect the piano and your mobile device, so that music played back from the mobile device can be heard through the piano's speakers, or so that you can use the piano with an app (p. 28).</p> <p>On, Off (default value: On)</p>
	Bluetooth Pairing	Perform the pairing to wirelessly connect the piano and mobile device for "Playing Music Through the Piano's Speakers" (p. 28).
	Bluetooth Volume	<p>Adjusting the Volume of Bluetooth Audio (Bluetooth Volume)</p> <p>This is the volume setting for playing music from your mobile device through the piano's speakers (p. 29).</p> <p>0–10 (default value: 4)</p>
	Bluetooth ID	<p>If you are using the Bluetooth function in a location where there are multiple pianos, you can assign a separate ID to each piano (p. 30).</p> <p>0–99 (default value: 0)</p>
Song playback settings		
Song Transpose		<p>Transposing the Pitch of the Song Playback (Song Transpose)</p> <p>You can transpose the song playback in semitone steps (p. 17).</p> <p>-12–0–+12 (default value: 0)</p>
Song Volume SMF		<p>Adjusting the Song (SMF) Volume (Song Volume SMF)</p> <p>This setting adjusts the volume of the song that is played back while you play the keyboard. This adjusts the volume of the song (SMF data) that is played back.</p> <p>0–10 (default value: 10)</p>
Song Volume Audio		<p>Adjusting the Song (Audio) Volume (Song Volume Audio)</p> <p>This setting adjusts the volume of the song that is played back while you play the keyboard. This adjusts the volume of the song (audio data) that is played back.</p> <p>0–10 (default value: 7)</p>
Input Volume		<p>Adjusting the Volume of an Audio Playback Device (Input Volume)</p> <p>This setting adjusts the volume of the song that is played back while you play the keyboard. You can adjust the volume of an audio playback device that's connected to the Input jacks.</p> <p>0–10 (default value: 7)</p>
USB Audio Input Vol.		<p>Adjusting the Volume from Your Computer (USB Audio Input Volume)</p> <p>When using a computer that's connected to the USB COMPUTER port to play back audio, adjust the volume using the computer.</p> <p>0–10 (default value: 7)</p>

English

日本語

Deutsch

Français

Italiano

Español

Português

Nederlands

简体中文

Configuring the Various Settings

Indication	Value	Explanation	
<h3>Settings Used for Playing Moving Key Using Commercially Available Data (Player Piano Data)</h3>			
<p>Use these settings to adjust the data type, accompaniment volume, piano sound timing and so on when the Moving Key function is used to play the piano with commercially available data (player piano data).</p>			
Player Piano Setting	Player PianoMode	Auto (default setting)	The data type is automatically determined.
		TypeA	Generally, player piano data contains both audio and MIDI data, so the data format depends on the data content. The piano makes a beeping noise if the data format doesn't match the settings on this instrument. Some player piano data can't be played back.
		TypeB	
		Off	Plays back the data as regular audio data.
	Audio Level	0–10 (default value: 7)	Adjusts the accompaniment volume.
	Audio Sync	-10–0–+10 (default value: 0)	With some data, the piano sound may get out of time with the accompaniment sound. If this happens, you can adjust the timing of the piano sound to make it match the accompaniment.
	Piano Mute	Off, On (default value: Off)	Stops the sound for the piano part and the Moving Key performance.
<h3>Specifying the Keyboard Tone for Song (SMF) Playback (SMF Play Mode)</h3>			
<p>This setting specifies the tone that you play on the keyboard while a song is playing back. Normally you will use the "Auto-Select" setting. This determines whether the setting that is most suitable for the internal song or most suitable for external data is selected when you play back a song whose file format is SMF.</p>			
<p>MEMO You can also switch the SMF Play Mode by holding down the [▶/■] button and pressing the [-] [+] buttons.</p>			
<p>* If the SMF playback mode is set to "External" some effects are not applied to the sound, meaning that the tonal character might differ from when you usually play the keyboard.</p>			
SMF Play Mode	Auto-Select (default setting)	Either "Internal" or "External" is selected automatically depending on the song that you play back.	
	Internal	When you play back a song, the tone that you play from the keyboard changes to the tone that is saved in the song. This is recommended when you play back an internal song or a song that you recorded on this piano.	
	External	The tone that you play from the keyboard does not change when you play back a song. This is recommended when you play back external data such as commercially available music data.	
<h3>Recording-related settings</h3>			
<p>This piano lets you record in two different modes. You can choose whether to record as SMF or as audio.</p>			
<p>MEMO You can also switch recording modes by holding down the [●] button and pressing the [-] [+] buttons.</p>			
Recording Mode	SMF (default setting)	Your performance is recorded to "Internal Memory" and played back on the piano. You can overdub your left-hand performance onto your right-hand performance, and then listen to the playback of both hands together (p. 24).	
	Audio	Your performance is recorded to a USB flash drive as audio data. You can listen to your recorded piano performance on a computer or audio player, use it to create a CD, or publish it on the internet (p. 25).	
Delete Song	Deletes a song that was saved in the piano's internal memory or on a USB flash drive (p. 23).		
Rename Song	Renames a saved song (p. 23).		
Copy Song	Songs that have been saved in internal memory can be copied to USB flash drive. Alternatively, songs stored on a USB flash drive can be copied to internal memory (p. 24).		
Count-in Measure	You can change the number of measures that are sounded as a count before song playback or recording begins.		
	1 Measure, 2 Measures (default value: 1 Measure)		
<h3>Pedal-related settings</h3>			
<h3>Changing How the Pedal Effects Are Applied (Damper Pedal Part)</h3>			
<p>When you depress the right pedal while the piano is in Dual Play or Split Play mode, the pedal effect is applied to both tones (p. 14). Use this setting to select the tone to which the effect is applied.</p>			
Damper Pedal Part	Right & Left (default setting)	All enabled	
	Right	Applied only to the Tone 1 (in dual mode)/Right-hand Tone (in split mode)	
	Left	Applied only to the Tone 2 (in dual mode)/Left-hand Tone (in split mode)	
<h3>Changing How the Pedals Work (Center Pedal)</h3>			
<p>When you turn on the power, the center pedal functions as the sostenuto pedal (p. 12). You can change the function of the pedal to a variety of other operations. By assigning a function to the pedal, you can instantly change a setting by pressing the pedal while you perform.</p>			
Center Pedal	Sostenuto (default setting)	The pedal functions as a sostenuto pedal.	
	Play / Stop	The pedal has the same function as the [▶/■] button. Note that playback doesn't work while the panel is locked.	
	Layer	Pressing the pedal will layer on Tone 2, used for Dual Play. * This is available only when using Dual Play.	

Indication	Value	Explanation
Changing the Effect of the Pedal (Left Pedal)		
When you turn on the power, the left pedal functions as a soft pedal (p. 12). You can change the function of the pedal to a variety of other operations. By assigning a function to the pedal, you can instantly change a setting by pressing the pedal while you perform.		
Left Pedal	Soft (default setting)	The pedal functions as a soft pedal.
	Play / Stop	The pedal has the same function as the [▶/■] button. Note that playback doesn't work while the panel is locked.
	Layer	Pressing the pedal will layer on Tone 2, used for Dual Play. * This is available only when using Dual Play.
Using the Pedal to Switch Between Registrations (Reg. Pedal Shift)		
You can use the pedal to switch between the registrations (p. 15). This lets you switch to the next registration by depressing the pedal. * The pedal function settings are prioritized as follows: "Reg. Pedal Shift" → "Center Pedal/Left Pedal".		
Reg. Pedal Shift	Off (default setting)	The registration doesn't change when you depress the pedal.
	Left Pedal	The left pedal (soft pedal) is used to switch between registrations. When doing so, you can't use the Left Pedal settings when assigned.
	Center Pedal	The center pedal (sostenuto pedal) is used to switch between registrations. When doing so, you can't use the Center Pedal settings when assigned.
MIDI-related settings		
Preventing Doubled Notes When Connected to a Sequencer (Local Control)		
When you have a MIDI sequencer connected via USB, set this parameter to Local Off. Since most sequencers have their Thru function turned on, notes you play on the keyboard may be sounded in duplicate, or get dropped. To prevent this, you can enable the "Local Off" setting so that the keyboard and internal sound generator will be disconnected.		
Local Control	On (default setting)	Local Control is on. The keyboard is connected to the internal sound generator.
	Off	Local Control is off. The keyboard is disconnected from the internal sound generator. Playing the keyboard will not produce sound.
MIDI Transmit Channel Settings (MIDI Transmit Ch.)		
This setting specifies the MIDI channel on which the unit will transmit. This unit will receive all sixteen channels (1–16).		
MIDI Transmit Ch.	Off, 1–16 (default value: 1)	
Overall operation settings		
Changing the Language Displayed in the Screen (Language)		
You can change the language that is displayed in the screen.		
Language	English, Japanese, Chinese (default value: English)	
Adjusting the Brightness of the Display (Display Contrast)		
You can adjust the brightness of the piano's display.		
Display Contrast	1–10 (default value: 5)	
Specifying the Time Until the Operating Panel Is Dimmed (Screen Saver)		
If no operations are performed for a specific length of time, the operating panel's button LEDs and display are dimmed. You can specify the time until they are dimmed.		
Screen Saver	Off, 30 sec., 1 min., 5 min., 10 min. (default value: off)	
Setting the Operating Panel Click Sound (Touch Click Volume)		
You can adjust the click sound that's heard when you touch the buttons on the operating panel.		
Touch Click Volume	Off, 1–10 (default value: 5)	
Specifying a Maximum Volume (Volume Limit)		
You can specify a maximum volume value. This lets you prevent loud sound from being produced unintentionally.		
Volume Limit	20, 40, 60, 80, 100 (maximum) (default value: 100)	
Adjusting the Haptic Key Vibration (Haptic Key Vibration)		
When a tone in the "Grand" group is selected, this simulates the way in which the keyboard vibrates when you play an acoustic piano. If headphones are connected, this function turns off. If you want the haptic key vibration characteristic of an acoustic piano to be added even when using headphones, set "Effect When Headphones Plugged" to "Effective". * When you switch the effect to "Effective" while using headphones, the haptic key vibration generator produces a slight sound resembling that of a real piano, even when you're listening to your playing via headphones.		
Haptic Key Vibration	Vibration Level	Off, Small, Standard, Large, Extra Large (default value: Standard)
	Effect When Headphones Plugged	Ineffective, Effective (default value: Ineffective)
Moving Key On/Off		
When you play back a song, the keys move automatically in time with the song.		
Moving Key On/Off	On, Off (default value: On)	

English

日本語

Deutsch

Français

Italiano

Español

Português

Nederlands





简体中文

Configuring the Various Settings

Indication	Value	Explanation
Moving Key Ch.		This specifies the MIDI channels used for playing the Auto Player.
	Auto (default setting)	Automatically detects which channel is used to make the keyboard play, based on the sound settings in the song.
	3&4	Sets the MIDI channels to channels 3 and 4, which are used to make the keyboard play. * The internal songs and the piano parts recorded on this instrument were recorded using MIDI channels 3 and 4.
	1-16	Specifies the channel used to make the keyboard play.
Auto-Power Off When Keyboard Cover is Closed	Turning Off the Power When You Close the Keyboard Cover (Power Off by the Lid)	
		You can choose whether the power turns off when you close the keyboard cover.
	Effective (default setting)	The power turns off when you close the keyboard cover.
	Ineffective	The power does not turn off when you close the keyboard cover. To turn off the power, press the [⏻] button. * If Auto Off is specified, the power automatically turns off when a certain length of time has elapsed after you stop playing or operating the instrument.
Speaker Auto Mute	Outputting Sound from Both Headphones and the Built-in Speakers (Speaker Auto Mute)	
		By factory default, the built-in speakers are set not to make sound when you connect a pair of headphones into the Phones jack. By changing the settings, you can make sound come from both the headphones and the built-in speakers. * Changing the setting to "Off" also changes the tonal character of the sound you hear in your headphones.
	Off	Sound comes from both headphones and built-in speakers.
	On (default setting)	Sound comes only from headphones.
Assignable Out	Sets the audio that's output from the Assignable Out connectors.	
	Main (default setting)	Outputs the same audio as the Output jacks.
	Backing	When a song is playing back, this outputs the audio except for what you are playing. The ambience effect is not applied.
	Dry	Outputs audio without the ambience effect, including what you're playing.
	Ambience	Only the ambience effect that's added to the original sound is output. This lets you create the feeling of playing in a hall, by outputting audio to separate speakers.
Auto Off	Making the Power Automatically Turn off After a Time (Auto Off)	
		With the factory settings, the unit's power automatically switches off after you stop playing or operating the unit for the amount of time you set. (This is the factory default setting.) If you don't want the power to turn off automatically, change the "Auto Off" setting to "Off".
		Off, 10 min., 30 min., 240 min. (default value: 30 min.)
Registration Export		
Registration Import		You can save your favorite settings or the piano's setup to a USB flash drive, or load these settings that are saved to a USB flash drive into the piano (p. 31).
Piano Setup Export		* Settings can be loaded only into another piano of the same model.
Piano Setup Import		
Format Media		All files saved in the piano's internal memory or on a USB flash drive (commercially available) can be deleted (p. 32).
Factory Reset		Here's how to restore all registrations and internally saved settings to the factory-set condition (p. 32).
Version		Displays the version of the unit's system program. If a new system program becomes available, it can be used to update your piano. For details, refer to the following URL. https://www.roland.com/support/ Enter the model name → refer to "Updater and Driver"

Keyboard Mode

Basic Settings in Keyboard Mode

1. Press the  button.
The  button is lit, and the piano is in keyboard mode.
2. Press the [-] [+] buttons to access the screen of the item you want to set.
3. Press the [↵] knob to confirm.
4. Press the [-] [+] buttons to select the value.
5. Press the  button to exit keyboard mode.
The  button goes dark.

Indication	Value	Explanation			
Keyboard-related settings					
Keyboard Mode	Whole	The same keyboard setting as a conventional acoustic piano.			
	Split	Playing Different Tones with the Left and Right Hand (Split Play)			
		You can perform using different tones in the left and right regions of the keyboard, divided at a specific note. This function is called "Split Play" (p. 14).			
		Point	Select the location (key) where the sound changes as you go from lower notes to higher notes. * The key (split point) that you choose is included in the left-side key range.		
		Balance	Selects the volume balance between the left-side and right-side tones.		
		Left Shift	Shifts the pitch of the notes you play in the left hand, up or down in octaves.		
	Right Shift	Shifts the pitch of the notes you play in the right hand, up or down in octaves.			
	Dual	Layering Two Tones (Dual Play)			
		You can play two tones simultaneously from a single key. This function is called "Dual Play" (p. 14).			
		Balance	Changing the volume balance of the two tones		
		Tone1 Shift	Shifts the pitch of tone 1, up or down in octaves.		
	Tone2 Shift	Shifts the pitch of tone 2, up or down in octaves.			
	Twin Piano	Dividing the Keyboard for Two People (Twin Piano)			
		You can divide the keyboard into left and right areas so that two people can play the same range of pitches. One person can play a model performance, and the other person can practice along with that model performance. You can also change the way (Mode) in which notes are sounded in Twin Piano. * If you select a tone from the "Grand" group, it sounds different than usual.			
		Twin Piano Mode	<table border="1"> <tr> <td>Pair (default setting)</td> <td>Notes played in the right zone are louder in the right speaker; notes played in the left zone are louder in the left speaker.</td> </tr> <tr> <td>Individual</td> <td>Notes played in the right area are heard only from the right speaker; notes played in the left area are heard only from the left speaker. When using headphones, you won't be able to hear the other person's playing.</td> </tr> </table>	Pair (default setting)	Notes played in the right zone are louder in the right speaker; notes played in the left zone are louder in the left speaker.
Pair (default setting)	Notes played in the right zone are louder in the right speaker; notes played in the left zone are louder in the left speaker.				
Individual	Notes played in the right area are heard only from the right speaker; notes played in the left area are heard only from the left speaker. When using headphones, you won't be able to hear the other person's playing.				
Kbd Transpose	The keyboard can be transposed in semitone steps. When accompanying a vocal, or when performing as a singer-instrumentalist, you can transpose the pitch to match the singer's pitch range without changing the fingering of your keyboard playing.				
	-6-0+5 (default value: 0)				
Key Touch	You can change the playing feel (touch) of the keyboard. The default value of 50 provides a key touch that is closest to that of an acoustic piano. Higher settings make the keyboard feel heavier. With the "Fix", notes sound at a fixed volume regardless of how strongly you play the keyboard.				
	Fix, 1-100 (default value: 50)				
Hammer Response	Adjusts the time from when you play the key until the piano sound is heard. Higher values produce a greater delay.				
	Off, 1-10 (default value: 1)				

English

日本語

Deutsch

Français

Italiano

Español

Português

Nederlands

简体中文

Troubleshooting

Problem	Items to check	Cause/Action	Page
Problems with the piano's sound			
No sound	Is the volume turned down?	Raise the volume.	p. 12
	Could headphones or an adaptor plug be inserted in the Phones jack?	If headphones or an adaptor plug are inserted in the headphones jack, sound is not output from the speakers.	–
	If you want sound to be produced from headphones or external speakers, is the device connected correctly?		p. 7
	Could the "Local Control" setting be turned "Off"?	In function mode, turn the "Local Control" setting "On".	p. 35
Pitch of the keyboard or song is incorrect	Could you have made Transpose settings?	Disable the transpose features in the "Kbd Transpose" setting of Keyboard mode and "Song Transpose" settings of Function mode.	p. 15, p. 33
	Is the Master Tune setting appropriate?	When shipped from the factory, the reference pitch is set to "442.0 Hz". Check the "Master Tuning" setting of the Piano Designer function.	p. 26
	Is the setting for the Temperament correct?	When shipped from the factory, the tuning is set to "Equal temperament". Check the "Temperament" setting of the Piano Designer function.	p. 26
	Is the Single Note Tuning setting appropriate?	Check the Piano Designer function's "Single Note settings".	p. 27
Sounds are heard twice (doubled) when the keyboard is played	Could "Dual Play" be specified, so that two tones are layered?	Change the keyboard mode setting from "Dual" to "Whole".	p. 37
	Could the piano be connected to an external sequencer?	If you don't want the piano to be played from another sound module, set your music production software's "soft thru" setting to "Off". If the function mode "Local Control" setting is "On", turn the "Local Control" setting "Off".	– p. 35
Reverberation remains even if you defeat the Ambience effect	This simulates the depth and ambience of the acoustic piano's sound, and is not a malfunction. Even if the Ambience effect is off, the acoustic piano's own resonance remains.	You can also reduce the resonance by lowering the "Cabinet Resonance" value of the Piano Designer function.	p. 27
The sound of the higher notes suddenly changes from a certain key	This simulates the characteristics of an acoustic piano, and is not a malfunction. The sound will change where there is a change in the number of strings per key or a transition from wound strings to unwound strings.		–
When you press a key, the sound of a note you didn't press is also faintly heard	In some cases, a note you play might cause a different note (whose frequency is an integer multiple of the first note) to resonate, producing the sensation that the sound has changed; this is not a malfunction.	Lower the Piano Designer's "Full Scale String Res." value, or turn it off.	p. 27
A buzz or vibration occurs when you play the keyboard	This feature simulates the vibration that occurs when you play the keyboard of an acoustic piano; it is not a malfunction.	You can eliminate the keyboard vibration by turning the "Haptic Key Vibration" setting off in function mode.	p. 35
High-pitched ringing is heard	<p>If you don't hear it through headphones: It may be that the piano has malfunctioned. Contact either the dealer where you purchased your instrument, or Roland Support.</p> <p>If you also hear it through headphones: To decrease the metallic ringing, adjust the following settings.</p> <ul style="list-style-type: none"> • Ambience Depth (p. 13) • Piano Designer "Full Scale String Res." (p. 27) 		–
Low notes sound wrong, or are buzzy	Could the volume be set to maximum?	If the volume is at the maximum, the sound might be distorted depending on how you play the piano. If this occurs, lower the volume.	p. 12
	<p>If you also hear it through headphones: It may be that the piano has malfunctioned. Contact either the dealer where you purchased your instrument, or Roland Support.</p> <p>If you don't hear it through headphones: Objects near the piano are resonating because of the high volume of sound coming from the speakers. You can take the following measures to minimize resonances.</p> <ul style="list-style-type: none"> • Keep the volume down. • Locate the speakers 10–15 cm (4–6 inch) away from walls or other surfaces. • Move away from the objects that are resonating. 		–
Noise is sometimes heard when you change the master tuning or temperament while piano sound is being produced	Due to how the sound engine is structured, you might hear noise with grand piano tones if you change the master tuning or temperament while sound is being produced. This is not a malfunction.		–
The sound is heard differently depending on the tone settings	When using "Dual play" which layers two tones, or "Split play" which produces different tones in the left-hand and right-hand, the sound might be heard differently depending on the specific combination. For some combinations, the effect is not applied to the left-hand tone or to tone 2, but this is not a malfunction.		–

Problem	Items to check	Cause/Action	Page
Problems with the pedals			
Pedal does not work, or is "stuck"	Is the pedal connected correctly?	Check the pedal jack located on the bottom of the piano.	p. 8
	Could you have disconnected or connected the pedal cord while the power was on?	If you disconnect the pedal cord while the piano is powered-on, the pedal effect might remain applied. Connect or disconnect the pedal cord while the piano is powered off.	-
	Could you have changed the way in which the pedal effect is applied?	If the right pedal part is set to "Right" it applies only to the right-hand tone; if set to "Left", it applies only to the left-hand tone.	p. 34
	Could Twin Piano be turned on?	If Twin Piano is on, the right pedal will affect only the right-hand keyboard zone and the left pedal will affect only the left-hand keyboard zone.	p. 37
	Could you have changed the function of the pedal?	If the function of the sostenuto pedal (center pedal) or the soft pedal (left pedal) have been changed, they will not operate as the sostenuto pedal or the soft pedal. Restore the settings of the "Center Pedal" and "Left Pedal".	p. 34
	Are you operating the pedals correctly?	Check whether the operations are correct.	p. 12
Problems with song playback			
Only the sound of a particular instrument in a song does not play	When you press the [🔊] button, are there parts (Right, Left, Accomp) that are unlit in the screen?	Parts that are not shown in the screen do not sound. Select an unlit part to highlight it so that it produces sound.	p. 17
Song volume is inaudible or too low	Could the song volume be set too low?	Depending on the data format of the song, raise the "Song Volume SMF" or "Song Volume Audio" value.	p. 33
Changing the "Song Volume" does not change the volume.	Could the SMF Play Mode be set to "Internal"?	Set the SMF Play Mode to "External".	p. 34
The selected sound changes when you play back a song	Could the SMF Play Mode be set to "Internal"?	Set the SMF Play Mode to "External".	p. 34
Can't play back a song saved in USB flash drive	Is the file extension ".WAV" or ".MP3" or ".MID"?	This piano can play back three types of file: WAVE format or MP3 format audio files, and MIDI files.	p. 17
Names of songs saved on the USB flash drive do not appear in the screen	Is the file extension ".MID"? Could the song name information in the file be blank or consist only of spaces?	Song names can be shown in the screen only for files that have a ".MID" extension. If the song name information in the file is blank or consists only of spaces, the song name is not shown in the piano screen.	p. 17
Problems with recording			
Can't record	When you press the [🔊] button, is the part to be recorded blinking in the screen?	Select the part in the screen that you want to record, so that it blinks.	p. 24
Can't record audio	Is a USB flash drive connected to the USB Memory port?	Audio recording cannot be performed unless a USB flash drive is connected.	p. 25
Volume differs between recording and playback	Could the song volume be set too low?	Depending on the data format of the song, raise the "Song Volume SMF" or "Song Volume Audio" value.	p. 33
The tonal character of the piano changes when you record	Could you be recording with a tone that you created in Piano Designer?	Some of the Piano Designer settings might not be reproduced when you play back a song.	-
	Could you be playing back a song that you audio-recorded to an USB flash drive?	If you want to record with the same tonal character as when you play the keyboard, record your performance as SMF.	-
Other problems			
Even though you're using headphones to mute the sound, a thumping sound is heard when you play the keyboard	The keyboard of this piano is designed to simulate the mechanism of an acoustic piano. Even on an acoustic piano, a thumping sound is actually being produced when you press a key. Such sounds do not indicate a malfunction.		-
Marks appear on the cloth portion of the piano	If objects come into contact with the cloth area located around the music rest, the cloth might get wrinkled and appear marred or discolored. However, this does not affect the performance of this instrument.		-
Power turns off on its own	Could you have made settings so that the power automatically turns off when the piano has not been used for a time?	If you don't need the power to turn off automatically, turn the Auto Off setting "Off".	p. 36
Power does not turn on	Is the power cord connected correctly?		p. 8
The buttons of the operating panel do not work	Could you have enabled the "Panel Lock" setting to prevent inadvertent operation?	Disengage the "Panel Lock" setting.	p. 9
	Is the panel wet?	Thoroughly wipe off any moisture on the panel before using this instrument.	p. 11
	Did you come into contact with the touch switches when you turned on the power?	Try turning the power off and then on again.	p. 11
The volume level of the unit connected to Input jack is too low	Could the volume of the connected device be turned down?		-
	Is the input volume too low?		p. 33
Moving Key is not making the keys move	Might the "Moving Key On/Off" setting have been set to "Off"?		p. 19
	Is "Moving Key Ch." set correctly?		p. 19
	Has the volume on the device that's playing back the player piano data been set too low?		-

Error Messages

Indication	Meaning
Error 2	An error occurred during writing. The USB flash drive may be corrupted. Insert other USB flash drive and try again. Alternatively, you can initialize the USB flash drive ("Initializing the Memory (Format Media)" (p. 32)).
	The internal memory might be damaged. Format the internal memory ("Initializing the Memory (Format Media)" (p. 32)).
Error 10	No USB flash drive is inserted. Insert the USB flash drive and try again.
	The internal memory might be damaged. Format the internal memory ("Initializing the Memory (Format Media)" (p. 32)).
Error 11	There is not sufficient free memory in the save destination. Either insert other USB flash drive or delete unneeded files and try again ("Deleting a Saved Song" (p. 23)).
	An error occurred during reading. The USB flash drive may be corrupted. Insert other USB flash drive and try again. Alternatively, you can initialize the USB flash drive ("Initializing the Memory (Format Media)" (p. 32)).
Error 14	The internal memory might be damaged. Format the internal memory ("Initializing the Memory (Format Media)" (p. 32)).
	The file is unreadable. The data format is not compatible with the unit.
Error 15	This audio format is not supported. Use an WAV format (44.1 kHz, 16-bit linear) or MP3 format audio file.
Error 18	Internal memory capacity of the unit is full.
Error 30	The unit cannot deal with the excessive MIDI data sent from the external MIDI device. Reduce the amount of MIDI data sent to the unit.
Error 40	A MIDI transmission error has occurred. Check the connected MIDI device.
Error 43	There may be a problem with the system. Repeat the procedure from the beginning. If this message still displays after you have tried several times, contact Roland as shown below.
	The Auto Player stopped operating due to high temperatures. This feature cannot be used in places subject to temperature extremes (e.g., direct sunlight, near a heater, or other heat source). If this message still appears even though the instrument is not located in such a place, contact Roland as shown below.
Error 51	The USB Memory port was subjected to excessive current. Make sure that there is no problem with the USB flash drive, then turn the power off, then on again.



Roland Service Centers and Distributors

When you need repair service, access this URL and find your nearest Roland Service Center or authorized Roland distributor in your country.

<https://roland.cm/service>



Tone List

Grand

No.	Tone Name
1	Concert Piano
2	Stage Piano
3	Mellow Piano
4	Bright Piano

MEMO

You can adjust the Piano Designer "Piano Tone settings" for only the tones in the "Grand" group.

Upright/Classical

No.	Tone Name
Upright	
1	Upright Piano
2	Mellow Upright
3	Bright Upright
4	Rock Piano
5	Ragtime Piano
Classical	
6	Fortepiano
7	Mellow Forte
8	Bright Forte
9	Harpsichord
10	Harpsi 8'+4'

E.Piano/Organ

No.	Tone Name
E.Piano	
1	1976SuitCase
2	Tremolo EP
3	Pop EP
4	Vintage EP
5	Stage Phaser
6	60's EP
7	FM E.Piano
8	EP Belle
9	70's EP
10	E.Grand
11	Magical Piano
12	Clav.
Organ	
13	Pipe Organ
14	Nason Flt 8'
15	ChurchOrgan1
16	ChurchOrgan2
17	Combo Jz.Org
18	Ballad Organ
19	Gospel Spin
20	Full Stops
21	Mellow Bars
22	Light Organ
23	Lower Organ
24	60's Organ

Others

No.	Tone Name
Strings	
1	SymphonicStr1
2	Epic Strings
3	Rich Strings
4	Velo Strings
5	SymphonicStr2
6	Violin
7	Cello
8	Orchestra Str
9	Orchestra
10	OrchestraBrs
11	Soft Pad
12	Chamber Winds
13	Flute
14	Harp
15	Pizzicato Str
16	A.Bass+Cymb1
Voice	
17	Jazz Scat
Do Re Mi	
18	Do Re Mi 2 ^f
19	Do Re Mi 2 ^b
20	Do Re Mi 1 ^f
21	Do Re Mi 1 ^b
Drums	
22	STANDARD Set
23	ROOM Set
24	POWER Set
25	ELEC.Set
26	ANALOG Set
27	JAZZ Set
28	BRUSH Set
29	ORCH.Set
30	SFX Set
GM2	
31	Piano 1
32	Piano 1w
33	Piano 1d
34	Piano 2
35	Piano 2w
36	Piano 3
37	Piano 3w
38	Honky-tonk
39	Honky-tonk w
40	E.Piano 1
41	Detuned EP 1
42	Vintage EP
43	60's E.Piano
44	E.Piano 2
45	Detuned EP 2
46	St.FM EP
47	EP Legend
48	EP Phaser
49	Harpsi.
50	Coupled Hps.
51	Harpsi.w
52	Harpsi.o
53	Clav.
54	Pulse Clav.
55	Celesta
56	Glockenspiel
57	Music Box
58	Vibraphone
59	Vibraphone w
60	Marimba
61	Marimba w
62	Xylophone
63	TubularBells
64	Church Bell
65	Carillon
66	Santur
67	Organ 1
68	TremoloOrgan
69	60's Organ
70	Organ 2
71	Perc.Organ 1
72	Chorus Organ
73	Perc.Organ 2
74	Rock Organ
75	Church Org.1
76	Church Org.2
77	Church Org.3
78	Reed Organ
79	Puff Organ
80	Accordion 1

No.	Tone Name
81	Accordion 2
82	Harmonica
83	Bandoneon
84	Nylon-str.Gt
85	Ukulele
86	Nylon Gt o
87	Nylon Gt 2
88	Steel-str.Gt
89	12-str.Gt
90	Mandolin
91	Steel+Body
92	Jazz Guitar
93	Hawaiian Gt
94	Clean Guitar
95	Chorus Gt 1
96	Mid Tone Gt
97	Muted Guitar
98	Funk Guitar1
99	Funk Guitar2
100	Chorus Gt 2
101	Overdrive Gt
102	Guitar Pinch
103	DistortionGt
104	Gt Feedback1
105	Dist.Rhy Gt
106	Gt Harmonics
107	Gt Feedback2
108	AcousticBass
109	FingeredBass
110	Finger Slap
111	Picked Bass
112	FretlessBass
113	Slap Bass 1
114	Slap Bass 2
115	Synth Bass 1
116	WarmSyn.Bass
117	Synth Bass 3
118	Clav.Bass
119	Hammer Bass
120	Synth Bass 2
121	Synth Bass 4
122	RubberSyn.Bs
123	Attack Pulse
124	Violin
125	Slow Violin
126	Viola
127	Cello
128	Contrabass
129	Tremolo Str.
130	PizzicatoStr
131	Harp
132	Yang Qin
133	Timpani
134	Strings
135	Orchestra
136	60's Strings
137	Slow Strings
138	Syn.Strings1
139	Syn.Strings3
140	Syn.Strings2
141	Choir 1
142	Choir 2
143	Voice
144	Humming
145	Synth Voice
146	Analog Voice
147	OrchestraHit
148	Bass Hit
149	6th Hit
150	Euro Hit
151	Trumpet
152	Dark Trumpet
153	Trombone 1
154	Trombone 2
155	Bright Tb
156	Tuba
157	MuteTrumpet1
158	MuteTrumpet2
159	French Horn 1
160	French Horn2
161	Brass 1
162	Brass 2
163	Synth Brass1
164	Synth Brass3
165	AnalogBrass1
166	Jump Brass
167	Synth Brass2

English

日本語

Deutsch

Français

Italiano

Español

Português

Nederlands

简体中文

Tone List

No.	Tone Name	No.	Tone Name
168	Synth Brass4	255	Stream
169	AnalogBrass2	256	Bubble
170	Soprano Sax	257	Bird 1
171	Alto Sax	258	Dog
172	Tenor Sax	259	Horse Gallop
173	Baritone Sax	260	Bird 2
174	Oboe	261	Telephone 1
175	English Horn	262	Telephone 2
176	Bassoon	263	DoorCreaking
177	Clarinet	264	Door
178	Piccolo	265	Scratch
179	Flute	266	Wind Chimes
180	Recorder	267	Helicopter
181	Pan Flute	268	Car Engine
182	Bottle Blow	269	Car Stop
183	Shakuhachi	270	Car Pass
184	Whistle	271	Car Crash
185	Ocarina	272	Siren
186	Square Lead1	273	Train
187	Square Lead2	274	Jetplane
188	Sine Lead	275	Starship
189	Saw Lead 1	276	Burst Noise
190	Saw Lead 2	277	Applause
191	Doctor Solo	278	Laughing
192	Natural Lead	279	Screaming
193	SequencedSaw	280	Punch
194	Syn.Calliope	281	Heart Beat
195	Chiffer Lead	282	Footsteps
196	Charang	283	Gun Shot
197	Wire Lead	284	Machine Gun
198	Solo Vox	285	Laser Gun
199	5th Saw Lead	286	Explosion
200	Bass+Lead		
201	Delayed Lead		
202	Fantasia		
203	Warm Pad		
204	Sine Pad		
205	Polysynth		
206	Space Voice		
207	Itopia		
208	Bowed Glass		
209	Metallic Pad		
210	Halo Pad		
211	Sweep Pad		
212	Ice Rain		
213	Soundtrack		
214	Crystal		
215	Synth Mallet		
216	Atmosphere		
217	Brightness		
218	Goblins		
219	Echo Drops		
220	Echo Bell		
221	Echo Pan		
222	Star Theme		
223	Sitar 1		
224	Sitar 2		
225	Banjo		
226	Shamisen		
227	Koto		
228	Taisho Koto		
229	Kalimba		
230	Bagpipe		
231	Fiddle		
232	Shanai		
233	Tinkle Bell		
234	Agogo		
235	Steel Drums		
236	Woodblock		
237	Castanets		
238	Taiko		
239	Concert BD		
240	Melodic Tom1		
241	Melodic Tom2		
242	Synth Drum		
243	TR-808 Tom		
244	Elec.Perc.		
245	Reverse Cym.		
246	Gt FretNoise		
247	Gt Cut Noise		
248	BsStringSlap		
249	Breath Noise		
250	Fl.Key Click		
251	Seashore		
252	Rain		
253	Thunder		
254	Wind		

Internal Song List

No.	Song Name	Composer
Listening		
1	Ballade No.1	Fryderyk Franciszek Chopin
2	Aufschwung	Robert Alexander Schumann
3	"Ah, vous dirai-je, Maman"	Wolfgang Amadeus Mozart
4	An die Freude (Jazz Arrangement)	Ludwig van Beethoven
5	Jupiter from The Planets (Jazz Arrangement)	Gustav Holst
6	Nocturne, op.9-2	Fryderyk Franciszek Chopin
7	Jeux d'eau	Maurice Ravel
8	Amazing Grace	Hymn
9	Für Elise (Jazz Arrangement)	Ludwig van Beethoven
10	Sonate für Klavier Nr.14 1	Ludwig van Beethoven
11	Sonate für Klavier Nr.14 2	Ludwig van Beethoven
12	Sonate für Klavier Nr.14 3	Ludwig van Beethoven
13	Love Is Here To Stay	George Gershwin
14	Widmung S.566 R.253	"Robert Alexander Schumann Arranged by Franz Liszt"
15	Étude, op.10-12	Fryderyk Franciszek Chopin
16	Barcarolle	Fryderyk Franciszek Chopin
17	Zhavoronok	Mikhail Ivanovich Glinka, Arranged by Mily Alexeyevich Balakirev
18	Sonate für Klavier Nr.23 1	Ludwig van Beethoven
19	Sonate für Klavier Nr.23 2	Ludwig van Beethoven
20	Sonate für Klavier Nr.23 3	Ludwig van Beethoven
21	Valse, op.34-1	Fryderyk Franciszek Chopin
22	Polonaise op.53	Fryderyk Franciszek Chopin
23	Nocturne No.20	Fryderyk Franciszek Chopin
24	Die Forelle	Franz Peter Schubert, Arranged by Franz Liszt
25	Reflets dans l'Eau	Claude Achille Debussy
26	La Fille aux Cheveux de Lin	Claude Achille Debussy
27	La Campanella	Franz Liszt
28	Scherzo No.2	Fryderyk Franciszek Chopin
Ensemble		
*Songs corresponding to the included collection of scores, "Roland Piano Masterpieces".		
1	Piano Concerto No.1	Peter Ilyich Tchaikovsky
2	Piano Concerto No.2	Sergei Rachmaninoff
3	Canon (Jazz Arrangement)	Johann Pachelbel
4	Sicilienne (Jazz Arrangement)	Gabriel Fauré
5	Berceuse from Dolly Suite	Gabriel Fauré
6	Le jardin féerique from Ma mère l'Oye	Maurice Ravel
7	Le Quattro Stagioni "La Primavera"	Antonio Vivaldi
8	Marche Militaire Nr.1	Franz Peter Schubert
9	Waltz from the Sleeping Beauty	Peter Ilyich Tchaikovsky
10	L'Apprenti sorcier	Paul Dukas
11	Salut d'Amour	Edward Elgar
12	Pavane pour une infante défunte	Maurice Ravel
13	Menuett G Dur BWV Anh.114	Johann Sebastian Bach
14	Präludium C Dur BWV846	Johann Sebastian Bach
15	Türkischer Marsch	Wolfgang Amadeus Mozart
16	Für Elise	Ludwig van Beethoven
17	Türkischer Marsch	Ludwig van Beethoven
18	Auf Flügeln des Gesanges	Felix Mendelssohn
19	Étude, op.10-3	Fryderyk Franciszek Chopin
20	Valse, op.64-1	Fryderyk Franciszek Chopin
21	Fantaisie-Improptu	Fryderyk Franciszek Chopin
22	Träumerei	Robert Alexander Schumann
23	Dolly's Dreaming Awakening	Theodor Oesten
24	Brautchor	Wilhelm Richard Wagner
25	Liebesträume Nr.3	Franz Liszt
26	Ungarische Tänze Nr.5	Johannes Brahms
27	Clair de Lune	Claude Achille Debussy
28	1ère Arabesque	Claude Achille Debussy
29	Golliwog's Cakewalk	Claude Achille Debussy
30	Je te veux	Erik Satie
Entertainment		
*Songs corresponding to the included collection of scores, "Roland Piano Masterpieces".		
1	Someday My Prince Will Come	Frank Churchill
2	Heigh Ho	Frank Churchill
3	Mickey Mouse March	Jimmie Dodd
4	Let It Go	Kristen Anderson-Lopez, Robert Lopez
5	Under The Sea	Alan Menken
6	ANPAN MAN NO March	Takashi Miki
7	YUME WO KANAETE DORAEMON	Katsuhiko Kurosu
8	SANPO	Jo Hisaishi
9	Polovtsian Dances	Alexander Borodin
10	Ombra mai fù	George Frideric Handel
11	Lascia ch'io pianga	George Frideric Handel
12	Twinkle Twinkle Little Star	French Folk Song
13	Mary Had a Little Lamb	Traditional
14	Bear Song	American Folk Song
15	Ich Bin Ein Musikante	German Folk Song
16	Grand Father's Clock	Henry Work
17	HANA	Rentaro Taki
18	HAMABE NO UTA	Tamezo Narita
19	MOMIJI	Teiichi Okano

No.	Song Name	Composer
20	YUKI	Monbusho Shoka
21	Happy Birthday to You	Mildred Hill, Patty Hill
22	Jingle Bells	James Pierpont
23	We Wish You a Merry Christmas	Carol
24	Silent Night	Franz Gruber
25	Auld Lang Syne	Traditional
26	Lavender's Blue	Traditional
27	Aura Lee	George R. Poulton
28	Amazing Grace	Hymn
29	Little Brown Jug	Joseph Winner
30	When The Saints Go Marching In	Traditional
31	Greensleeves	Traditional
32	When I Fall in Love	Victor Young
33	Softly, as in a Morning Sunrise	Sigmund Romberg
34	As Time Goes By	Herman Hupfeld
35	Summertime	George Gershwin
36	Moonlight Serenade	Glenn Miller
37	Maple Leaf Rag	Scott Joplin
38	The Entertainer	Scott Joplin
39	Tico Tico no Fubá	Zequinha de Abreu
40	Tea for Two	Vincent Youmans
Do Re Mi Lesson		
*Songs corresponding to the included collection of scores, "Roland Piano Masterpieces".		
1-15	Training No.1 - 15	Roland Corporation
16	Twinkle Twinkle Little Star	French Folk Song
17	Summ,Summ,Summ	Traditional
18	Frog Song	German Folk Song
19	The Cuckoo	Traditional
20	Oh! Susanna	Stephen Foster
21	Let's Clap Hands	Traditional
22	Das klinget so herrlich	Wolfgang Amadeus Mozart
23	Wiegenlied	Johannes Brahms
24	Les Patineurs	Émile Waldteufel
25	Minuet	Johann Sebastian Bach
26	Old Folks At Home	Stephen Foster
27	Deck the Halls	Carol
28	Danny Boy	Irish Song
29	Korobeiniki	Russian Folk Song
30	Sakura Sakura	Japanese Folk Song
Scale		
*Songs corresponding to the included collection of scores, "Roland Piano Masterpieces".		
1-36	Major Scales, Minor Scales	-
Hanon		
1-20	1-20	Charles-Louis Hanon
Beyer		
1-106	1-106	Ferdinand Beyer

English

日本語

Deutsch

Français

Italiano

Español

Português

Nederlands

简体中文

Internal Song List

No.	Song Name	Composer
Burgmüller		
1	Openness	Johann Friedrich Franz Burgmüller
2	Arabesque	
3	Pastoral	
4	A Small Gathering	
5	Innocence	
6	Progress	
7	The Clear Stream	
8	Gracefulness	
9	The Hunt	
10	Tender Flower	
11	The Young Shepherdess	
12	Farewell	
13	Consolation	
14	Austrian Dance	
15	Ballad	
16	Sighing	
17	The Chatterbox	
18	Restlessness	
19	Ave Maria	
20	Tarantella	
21	Angelic Harmony	
22	Gondola Song	
23	The Return	
24	The Swallow	
25	The Knight Errant	
Czerny 100		
1-100	1-100	Carl Czerny

- * All rights reserved. Unauthorized use of this material for purposes other than private, personal enjoyment is a violation of applicable laws.
- * Songs marked by an asterisk (*) are arranged by Roland Corporation. The copyrights to these songs are owned by the Roland Corporation.
- * Songs in Listening category are piano solos. They have no accompaniment.
- * Please purchase commercially available scores for Hanon–Czerny no. 100.
- * The performance data for the tone demos and the internal songs is not transmitted from the USB Computer port or via **Bluetooth** (MIDI).
- * If the SMF Play Mode is set to “Internal”, there will be some parts whose volume does not change when you adjust the Song Volume SMF value. If the SMF Play Mode is set to “External”, the volume of all parts will change.